

Brussels, 24 April 2025 (OR. en)

8255/25 ADD 1

Interinstitutional File: 2025/0097(COD)

> TRANS 144 CODEC 471 ENV 274 MI 245

#### PROPOSAL

From:	Secretary-General of the European Commission, signed by Ms Martine DEPREZ, Director
date of receipt:	24 April 2025
То:	Ms Thérèse BLANCHET, Secretary-General of the Council of the European Union
No. Cion doc.:	COM(2025) 180 final - ANNEXES 1 to 2
Subject:	ANNEXES to the proposal for a Directive of the European Parliament and of the Council amending Directive 2014/45/EU on periodic roadworthiness tests for motor vehicles and their trailers and Directive 2014/47/EU on the technical roadside inspection of the roadworthiness of commercial vehicles circulating in the Union

Delegations will find attached document COM(2025) 180 final - ANNEXES 1 to 2.

Encl.: COM(2025) 180 final - ANNEXES 1 to 2



EUROPEAN COMMISSION

> Brussels, 24.4.2025 COM(2025) 180 final

ANNEXES 1 to 2

### **Roadworthiness package**

### ANNEXES

to the proposal for a Directive of the European Parliament and of the Council amending Directive 2014/45/EU on periodic roadworthiness tests for motor vehicles and their trailers and Directive 2014/47/EU on the technical roadside inspection of the roadworthiness of commercial vehicles circulating in the Union

 $\{ SEC(2025) \ 119 \ final \} - \{ SWD(2025) \ 96 \ final \} - \{ SWD(2025) \ 97 \ final \} - \{ SWD(2025) \ 98 \ final \} - \{ SWD(2025) \ 99 \ final \} \}$ 

## ANNEX I

Annexes I, III and IV to Directive 2014/45/EU are amended as follows:

- (1) Annex I is amended as follows:
- (a) in point 1, the second paragraph is replaced by the following:

'The test must cover at least the items listed in point 3 provided that the systems and components are fitted to the vehicle. The test may also include a verification as to whether the relevant parts and components of that vehicle correspond to the required safety and environmental characteristics that were in force at the time of approval or, where applicable, at the time of retrofitting.';

(b) in point 2, the following point is added:

'(10) Electronic safety systems.';

(c) point 3 is amended as follows:

(i) the heading and the introduction are replaced by the following:

'3. CONTENTS AND METHODS OF TESTING, REASONS FOR FAILURE, AND ASSESSMENT OF DEFICIENCIES OF VEHICLES

The test shall cover at least the items, and use the minimum standards and the recommended methods, listed in the table set out in this point.

The components and systems of the vehicle shall be inspected visually or by means of the electronic interface, or both, where applicable, using the following inspection criteria:

- (a) the inspection of the fitment includes the evaluation of any relevant diagnostic trouble codes and an examination of whether the fitted systems and components comply for example, with the following:
  - the given design, specified attachment/number, specified circuit, required marking;
  - the valid software version including the integrity feature;
- (b) the inspection of the condition includes an examination of whether the fitted systems and components are for example:
  - damaged, corroded, or aged;
  - properly fastened, secured, assembled, and routed;
  - operating freely and easily;
  - indicating failure via the malfunction indicator lamp (MIL) or, where applicable, via the on-board monitoring (OBM) system;
  - ready to be inspected (readiness);
- (c) the inspection of the functioning includes an examination of the actuation and/or activation including that of the pedals, levers, switches, or operating devices, which initiate an action and of the electronically controlled systems and components, for example, actuators, to ensure that they are operating correctly in terms of timing and function;

- (d) the inspection of the performance and efficiency is a metrological inspection of a component or system for compliance with, or achievement of, specified limit values, which may also include calculation, such as the following:
  - testing the brakes on a brake tester and calculating the efficiency (where applicable by means of reference values);
  - activation of a safety system and evaluating sensor values and/or measuring the performance with external test equipment.

As regards electronic periodic technical inspection (ePTI) using the electronic vehicle interface, an ePTI system list is defined in EN ISO 20730-3:2021. Those electronic safety systems are referred to in item 10 of the table set out in this point.

For each vehicle system and component subject to testing, the assessment of deficiencies is to be carried out, on a case-by-case basis in accordance with the criteria laid down in the table set out in this point.

Deficiencies not listed in this Annex shall be assessed in terms of the risks that they pose to road safety.';

(ii) in the table, items 1.1.3 to 1.1.6 are replaced by the following:

1.1.3. Vacuum pump or compressor and reservoirs	Visual inspection of the components at normal working pressure. Check time required for vacuum or air pressure to reach safe working value and function of warning device, multi-circuit protection valve and pressure relief valve.			Х	х
	Brake application means depression of the brake pedal/lever which allows the full flow of air/fluid application pressure to the brake assemblies.	(b) Time taken to build up air pressure/vacuum to safe working value is too long according to the require- ments <sup>1</sup>		Х	
		(c) Multi-circuit protection valve or pressure relief valve not working.		Х	
		(d) Air leak causing a noticeable drop in pressure or audible air leaks.		Х	
		Air leak causing a critical drop in pressure.			Х
		(e) External damage likely to affect the function of the braking system.		Х	
		Secondary braking performance not met.			Х
1.1.4. Low pressure warning device	Functional check	Malfunctioning or defective warning device.	Х		
		Low pressure not identifiable.		Х	
1.1.5. Hand-operated brake control valve	Visual inspection of the components while	(a) Control cracked, damaged or excessively worn.		Х	
	the braking system is operated.	(b) Control insecure on valve or valve insecure.		Х	
		(c) Loose connections, defective fixing, or leaks in system.		Х	
		(d) Unsatisfactory operation.		Х	

1.1.6. Parking brake (activator, lever control, parking brake ratchet)		(a) Ratchet not holding correctly.		Х	
control, parking orace ratefield		(b) Wear at lever pivot or in ratchet mechanism.	Х		
		Excessive wear.		Х	
		(c) Excessive movement of lever indicating incorrect adjustment.		Х	
		(d) Activator missing, damaged or inoperative.		Х	
		(e) Incorrect functioning, warning indicator shows malfunction		Х	

6

(iii) in the table, item 1.1.13 is replaced by the following:

1.1.13.	Brake linings and pads	Visual inspection.	(a) Lining or pad excessively worn (minimum mark reached).	Х	
			Lining or pad excessively worn (minimum mark not visible).		Х

(b) Lining or pad contaminated (oil, grease etc.).		Х	
Braking performance affected.			Х
(c) Lining or pad missing or wrongly mounted, or of obviously incorrect type.			Х
(d) Wear indicator electrical harness disconnected or damaged	Х		

6

(iv) in the table, item 1.1.18 is replaced by the following:

1.1.18.	1.1.18. Slack adjusters and indicators	Slack adjusters and indicators	Visual inspection of the components while the braking system is operated, if possible.	(a) Adjuster damaged, seized or having abnormal movement, excessive wear, or incorrect adjustment.	Х	
		(b) Adjuster defective.	Х			
		(c) Incorrectly installed or replaced.	Х			

';

6

';

(v) in the table, item 1.1.19 is deleted;

(vi) in the table, item 1.1.23 is replaced by the following:

1.1.23. Overrun brake	Visual inspection and by operation	<ul> <li>(a) Not working properly, for example, stroke of the drawbar exceeds 2/3 of the total overrun travel</li> </ul>	Х	
		(b) Breakaway cable defect or missing	Х	

(vii) in the table, items 1.2.1 and 1.2.2 are replaced by the following:

EN

1.2.1. Performance	impossible, during a road test, apply the	(a) Inadequate braking effort on one or more wheels.	Х	
	brakes progressively up to maximum effort. It must be ensured, where possible, that the mechanical service brakes are inspected without interference/blending of	Or, in the case of testing on the road, the vehicle deviates excessively from a straight line and/or excessive vibration is produced at the service brake pedal/lever.	Х	
	regenerative braking or other continuous braking.	No braking effort on one or more wheels.		Х
		(b) Braking effort from any wheel is less than 70 % of the maximum effort recorded from the other wheel on the same axle. Or, in the case of testing on the road, the vehicle deviates excessively from a straight line.	X	
		Braking effort from any wheel is less than 50 % of the maximum effort recorded from the other wheel on the same axle in the case of steered axles.		Х
		(c) No gradual variation in brake effort (grabbing).	Х	
		(d) Abnormal lag in brake operation of any wheel.	Х	
		(e) Excessive fluctuation of brake force during each complete wheel revolution.	Х	

1.2.2. Efficiency	Test with a brake tester or, if one cannot be used for technical reasons, by a road test using a deceleration recording instrument to establish the braking ratio which relates <ul> <li>(a) to the maximum authorised mass or,</li> <li>(b) in the case of semi-trailers, to the sum of the authorised axle loads, or</li> <li>(c) to reference values.</li> </ul> <li>Vehicles or a trailer with a maximum</li>
	permissible mass exceeding 3,5 tonnes must be inspected following the standards given by ISO 21069 or equivalent methods.       2. Vehicles registered for the first time before 1/1/2012:       X         For vehicles not inspected following the standards given by ISO 21069 or equivalent methods, if the minimum figure of braking ratio is not achieved, at least meaningful brake testing must be performed. Meaningful brake testing is performed if brake efficiency is below       2. Vehicles registered for the first time before 1/1/2012:       X
	the service, secondary or parking values       3. Other categories       X         prescribed in 1.2.2 or 1.3.2 or 1.4.2 but all the following conditions are met:       3. Other categories       X         — the braking system is in good condition with no obvious defects,       — Categories L2e, L6e: 40 %       — Category L3e: 50 %         — wheels of all axles lock because adhesion between the tyre and brake tester surface was exhausted during the brake test; if wheels on some axles do not lock, it must be safely concluded that the braking efficiency values prescribed in 1.2.2 or 1.3.2 or 1.4.2 would be achieved when the vehicle is loaded,       Category T: 40%       Category T: 40%         Less than 50 % of the above values reached.       X
	Information on system values may be retrieved using electronic vehicle interface.

	Road tests should be carried out under dry conditions on a flat, straight road. In cases where vehicles of R or T category are tested on the road, meaningful brake testing is performed if all the above conditions are met. In case of doubt, the braking efficiency shall be demonstrated in loaded or partially loaded condition.				
--	---	--	--	--	--

4

# (viii) in the table, item 1.3.1 is replaced by the following:

.3.1. Performance	If the secondary braking system is separate from the service braking system, use the method specified in 1.2.1.		Х	
	It must be ensured that, where possible, the mechanical brakes are inspected without	No braking effort on one or more wheels.		X
		(b) Braking effort from any wheel is less than 70 % of the maximum effort recorded from another wheel on the same axle specified. Or, in the case of testing on the road, the vehicle deviates excessively from a straight line.	Х	
		Braking effort from any wheel is less than 50 % of the maximum effort recorded from the other wheel on the same axle in the case of steered axles.		X
		(c) No gradual variation in brake effort (grabbing).	Х	

6

';

6

(ix) in the table, item 1.4.1 is replaced by the following:

1.4.1. Performance	Apply the brake during a test on a brake tester or by road test.	Brake inoperative on one side or, in the case of testing on the road, the vehicle deviates excessively from a straight line.	Х	
		Less than 50 % of the braking effort values as referred to in point 1.4.2 reached in relation to the vehicle mass during testing.		X

(x) in the table, item 1.5 is replaced by the following:

1.5.	Endurance braking system performance	Visual inspection and, where possible, test whether the system functions, i.e. by road test.	(a) Malfunction indicator indicates a fault.	Х	
			(b) System not functioning.	Х	

';

6

(xi) in the table, item 1.6 is deleted;

(xii) in the table, item 1.7 is replaced by the following:

1.7.	Electric regenerative braking	Visual inspection of the indicator of electric	(a) Warning device indicates malfunctioning. X	
		regenerative braking, and, where made possible by the technical characteristics of the vehicle and where the necessary data is made available, by using the electronic	(b) The system does not noticeably decelerate the vehicle, or the charge indicator (if fitted) does not display "on charge" when regeneration is activated.	
		vehicle interface, or by road test.	(c) Vehicle interface indicates system malfunction. X	

4

(xiii) in the table, item 2.6 is deleted;

(xiv) in the table, items 4.1.1, 4.1.2 and 4.1.3 are replaced by the following:

4.1.1. Condition and operation	Visual inspection and by operation.	(a) Defective or missing light source.			
		Multiple light sources (in the case of LED, up to 1/3 not functioning).	Х		
		Seriously affected visibility.		Х	
		(b) Slightly defective projection system (reflector and lens).	Х		
		Heavily defective or missing projection system (reflector and lens).		Х	
		(c) Lamp not securely attached.		Х	
		(d) System indicates failure for example via the electronic vehicle interface.		Х	
4.1.2. Alignment	Determine the horizontal and vertical aim of each headlamp on dipped beam using a headlamp aiming device.	(a) Aim of a headlamp not within limits laid down in the requirements <sup>1</sup> . If there are no specific requirements, the following reference values shall be used, where h is the height of headlamp (lowest point of the light-emitting surface):		Х	
		<ul> <li>(i) M,N,O categories (Regulation No 48 UN/ECE [2016/1723], point 6.2.6.1.2):</li> </ul>			
		- $h \le 0.8m$ : upper limit -0.5%; lower limit -2.5%			
		<ul> <li>— 0.8 &lt; h ≤ 1m: upper limit -0.5%; lower limit -3%</li> <li>— h &gt; 1m: upper limit -1% e inferior -3%</li> </ul>			
		<ul> <li>h &gt; 1.2m, category N3G (all-terrain): upper limit - 1.5%; lower limit -3.5%</li> </ul>			
		<ul> <li>L category (Commission Delegated Regulation (EU) No 3/2014 and Regulation No 53 UN/ECE):</li> </ul>			
		- upper limit -0.5% - $h \le 0.8m$ : lower limit -2.5% $h \ge 0.8m$ : lower limit -2.0% (2.5%) on L2a extension)			
		— h > 0.8m: lower limit -3,0% (-2,5% on L3e category)			
		(iii) T category (Regulation No 86 UN/ECE):			

	<ul> <li>— upper limit -0.5%</li> <li>— h ≤ 1,2m: lower limit -4%</li> </ul>		
	h > 1,2m: lower limit -6%		

4.1.3. Switching	Visual inspection and by operation	<ul> <li>(a) Switch does not operate in accordance with the requirements<sup>1</sup> (Number of headlamps illuminated at the same time)</li> </ul>	Х		
		Maximum permitted light brightness to the front exceeded.		Х	
		(b) Function of control device impaired.		Х	

# (xv) in the table, item 4.1.5 is replaced by the following:

4.1.5. Manual levelling devices (where mandatory)	Visual inspection and by operation, if possible, or using the electronic vehicle		Х	
	interface	(b) device cannot be operated from driver's seat.	Х	

#### ';

6

';

6

(xvi) in the table, item 4.2.1 is replaced by the following:

4.2.1.	Condition and operation	Visual inspection and by operation.	<ul><li>(a) Defective or missing light source</li><li>Multiple light sources (in the case of LED, up to 1/3 not functioning); one of several lateral light sources defective.</li></ul>	Х		
			Seriously affected visibility (in the case of LED, less than 2/3 functioning).		Х	
			(b) Defective lens.		Х	
			(c) Lamp not securely attached.	Х		
			Very serious risk of falling off.		Х	

6

(xvii) in the table, items 4.3.1 and 4.3.2 are replaced by the following:

.3.1. Condition and operation	Visual inspection and by operation.	(a) Defective or missing light source.			
		Multiple light sources; in the case of LED up to 1/3 not functioning.	Х		
		Single light sources; in the case of LED less than 2/3 functioning.		x	
		No light source functioning.			Х
		(b) Slightly defective lens (no influence on emitted light).	Х		
		Heavily defective lens (emitted light affected).		X	
		(c) Lamp not securely attached.	Х		
		Very serious risk of falling off.		X	
3.2. Switching	Visual inspection and by operation	(a) Switch does not operate in accordance with the requirements <sup>1</sup> .	Х		
		Delayed operation.		Х	
		No operation at all.			Х
		(b) Function of control device impaired.		Х	

(xviii) in the table, item 4.4.1 is replaced by the following:

.4.1. Condition and operation	Visual inspection and by operation.	(a) Defective or missing light source			
		Multiple light sources ( in the case of LED up to $1/3$ not functioning).	Х		
		Single light sources; in the case of LED less than 2/3 functioning.		Х	
		No light source functioning.			X
		(b) Slightly defective lens (no influence on emitted light).	Х		
		Heavily defective lens (emitted light affected).		Х	
		(c) Lamp not securely attached.	Х		
		Very serious risk of falling off.		Х	

(xix) in the table, item 4.5.1 is replaced by the following:

4.5.1.	Condition and operation	Visual inspection and by operation.	(a) Defective or missing light source.			
			Multiple light sources ( in the case of LED up to $1/3$ not functioning).	Х		
			Single light sources; in the case of LED less than 2/3 functioning.		Х	
			(b) Slightly defective lens (no influence on emitted light).	Х		
			Heavily defective lens (emitted light affected).		Х	
			(c) Lamp not securely attached.	Х		
			Very serious risk of falling off or dazzling oncomingtraffic.		Х	

6

(xx) in the table, item 4.6.1 is replaced by the following:

.6.1. Condition and operation	Visual inspection and by operation.	(a) Defective or missing	light source		
		Multiple light sources (in functioning).	the case of LED up to 1/3 not X		
		Single light sources; in t functioning.	he case of LED less than 2/3	Х	
		(b) Defective lens	Х		
		(c) Lamp not securely attack	hed. X		
		Very serious risk of fal	ling off	Х	

';

6

(xxi) in the table, item 4.7.1 is replaced by the following:

4.7.1. Condition and operation	Visual inspection and by operation.	(a) Lamp throwing direct or white light to the rear.	Х		
		(b) Defective or missing light source. (Multiple light source).	Х		
		Defective or missing light source. (Single light source).		Х	
		(c) Lamp not securely attached.	Х		
		Very serious risk of falling off.		Х	

';

(xxii) in the table, item 4.11, the title in the first column of the table is replaced by the following:

'Electrical wiring (except high-voltage wiring)';

(xxiii) in the table, item 4.13, the title in the first column of the table is replaced by the following: 'Battery (or batteries, except high-voltage batteries)';

(xxiv) the following item 4.14 is inserted:

4.14 High-voltage systems					
4.14.1 Electrical safety	Visual inspection complemented by using the vehicle interface	(a) Indicator or vehicle interface shows system malfunction		Х	
		(b) Software version or -integrity incorrect		Х	
4.14.2 Traction battery cover	Visual inspection.	(a) Slightly deteriorated	Х		
		Heavily deteriorated		х	
		<ul><li>(b) Defective attachment</li><li>Very serious risk of falling off</li></ul>		Х	х
		(c) Obstructed ventilation port(s)	Х		
4.14.3 Traction battery	Visual inspection, complemented by using the vehicle interface (where made possible by the technical characteristics of the vehicle, and where the necessary data is available).	<ul><li>(a) Marks of leakage</li><li>Leaking (presence of droplets)</li></ul>		Х	х
		(b) Incorrect software or hardware, or readiness-code not active		Х	
4.14.4 High voltage electrical wiring					
4.14.4.1 High voltage wiring harness and connector	Visual inspection and by operation with the vehicle over a pit or on a hoist, including	(a) Slightly deteriorated Heavily deteriorated	Х	Х	
	inside the engine compartment and the boot (where applicable)	Risk of short-circuit fault			Х
		<ul> <li>(b) Wiring insecure or not adequately secured Fixings loose, touching sharp edges, connectors</li> </ul>	Х	Х	

		likely to be disconnected Wiring likely to touch hot parts, rotating parts or the ground, connectors disconnected			Х
		(c) Imminent risk of fire, formation of sparks			Х
4.14.4.2 Ground braid, including their attachment	Visual inspection and by operation.	Slightly deteriorated Heavily deteriorated	Х	Х	
4.14.4.3 Ground continuity (X) <sup>2</sup>	Measurement using an ohmmeter	Test not feasible Too high resistance (over 100 Ohms)	Х	x	
4.14.4.4 Charging inlet cover	Visual inspection and by operation.	Deteriorated Missing	Х	х	
4.14.4.5 Charging inlet	Visual inspection and by operation.	<ul><li>(a) Deteriorated Trace of beginning of melting or electric arcs</li><li>(b) Foreign material or moisture</li></ul>	Х	X X	
4.14.4.6 Charging cable	Visual inspection and by operation.	<ul><li>(a) Deteriorated</li><li>(b) Charging cable not provided</li></ul>	X X		
4.14.5. High voltage electrical and electroni	ical equipment (X) <sup>2</sup>	(-)			
4.14.5.1. High voltage electrical and electronical equipment	Visual inspection and by using the electronic vehicle interface.	<ul> <li>(a) Slightly deteriorated Heavily deteriorated</li> <li>(b) Attachment defective</li> </ul>	Х	X X	
		(c) Leaking		X	
4.14.5.2. Traction motor	Visual inspection	(a) Shield is deformed, not in-place or damaged, or corroded		Х	
	Check of operational readiness of the	(b) Warning marking missing or illegible		Х	
	systems by an applicable interface (OBD or OBM)	(c) Connection of wiring harness insecure or corroded		Х	
	Measurement of equipotential bonding, where made possible by the technical	<ul> <li>(d) Electrical insulation damaged or deteriorated likely to cause injury when contacted.</li> </ul>		Х	Х
	characteristics of the vehicle	(e) Fault readiness of the traction motor		Х	

		(f) Wrong version of type-approved hardware and software not in accordance with the requirements as defined in the ECE R100		Х	
4.14.5.3 Electronic converters, motor, and	Visual inspection	(a) Not in accordance with requirements <sup>1</sup>		Х	
inverter	Check of operational readiness of the	(b) Inadequately secured		Х	
	systems by an applicable interface (OBD or OBM)	(c) Damaged or corroded components	Х		
	ODW)	Likely to cause injuries or to fall off		Х	
	Measurement of equipotential bonding,	(d) Shields not in place or damaged		Х	
	where made possible by the technical characteristics of the vehicle	(e) Damaged or deteriorated electrical insulation		Х	
		(f) Fault readiness of the converter and inverter systems		Х	
		<ul> <li>(g) Wrong version of type-approved hardware and software</li> </ul>		Х	
4.14.6. Insulation resistance (X) <sup>2</sup>					
4.14.6.1. Insulation resistance of the vehicle charging inlet and resistance of the protective earthing	Read insulation resistance by the electronic vehicle interface, where made possible by the technical characteristics of the vehicle	<ul> <li>(a) Insulation resistance is not in accordance with requirements or predefined values from the vehicle manufacturer</li> </ul>		Х	
	and where the necessary data is made available	(b) Resistance of the protective earthing is not in accordance with requirements		Х	
4.14.6.2. Insulation resistance between the	Visual inspection	(a) Insulation monitoring system shows malfunction		Х	
high-voltage system and chassis	Read insulation resistance by the electronic vehicle interface, where made possible by the technical characteristics of the vehicle and where the necessary data is made available	(b) Insulation resistance value not in accordance with requirements		Х	
4.14.7. Anti-starting system				<u> </u>	
4.14.7.1. Anti-starting system	Visual inspection and by operation when possible.	(a) Indicator malfunction	Х		
	Functional check by verifying that the vehicle cannot move by itself with the charging cable plugged, and the driver's weight lifted out of the seat	(b) Inoperative, i.e., vehicle can move with connected charging cable or with no driver present		Х	

6

(xxv) in the table, item 5.1.3 is replaced by the following:

5.1.3. Wheel bearings	Visual inspection with the vehicle over a pit	(a) Excessive play in a wheel bearing.	Х	
	or on a hoist. Wheel play detectors may be used and are recommended for vehicles having a maximum mass exceeding 3,5 tonnes. Rock the wheel or apply a lateral force to each wheel and note the amount of upward movement of the wheel relative to the stub axle.	Directional stability impaired; danger of demolishment.		Х
		(b) Wheel bearing too tight, jammed.	Х	
		Danger of overheating; danger of demolishment.		Х
		(c) Audible signs of bearing wear or damage.	Х	

';

4

(xxvi) in the table, item 5.2.3 is replaced by the following:

5.2.3. Tyres	Visual inspection of the entire tyre by either rotating the road wheel with it off the ground and the vehicle over a pit or on a hoist, or by rolling the vehicle backwards and forwards over a pit.	affecting road safety or environmental performance.	Х	х
		(b) Tyres on same axle or on twin wheels of different sizes.	Х	

(c) Tyres on same axle of different construction (radial/ cross-ply).		Х	
(d) Any serious damage or cut to tyre.		Х	
Cord visible or damaged.			Х
(e) Tyre tread wear indicator becomes exposed.		Х	
Tyre tread depth not in accordance with the requirements <sup>1</sup> .			Х
(f) Tyre rubbing against other components (flexible anti spray devices).	Х		
Tyre rubbing against other components (safe driving not impaired)		Х	
(g) Re-grooved tyres not in accordance with require- ments <sup>1</sup> .		Х	
Cord protection layer affected.			Х
(h) Tyre obviously underinflated.	Х		

# (xxvii) in the table, item 5.3.2.1 is replaced by the following:

5.3.2.1. efficiency testing of dampi		(a) Significant difference between left and right.	Х	
	left/ right differences, or based on measurement of oscillation behaviour or damping of the vehicle	(b) Given minimum values not reached.	Х	

';

4

';

6

(xxviii) in the table, items 7.1.3, 7.1.4, 7.1.5 and 7.1.6 are deleted;

(xxix) in the table, item 7.8 is replaced by the following:

road test or by using the electronic vehicle interface, or any combination of these.		(a) Not fitted in accordance with the requirements <sup>1</sup> .	Х			
		Missing (if required).		Х		
	(b) Operation impaired.	Х				
		Not operational at all.		Х		
			(c) Not capable of being sufficiently illuminated.	Х		
			Not capable of being illuminated at all.		Х	

4

';

6

(xxx) in the table, items 7.9 and 7.10 are deleted;

(xxxi) in the table, item 7.11 is replaced by the following:

7.11.	Odometer, if available	Visual inspection, and/or using electronic interface (OBD or OBM)	(a) Obviously manipulated (fraud) to reduce or misrepresent the vehicle's distance record.	Х	
			(b) Obviously inoperative.	Х	

(xxxii) in the table, items 7.12 and 7.13 are deleted;

(xxxiii) in the table, items 8.1 and 8.2 are replaced by the following:

8.1. Noise

8.1.1. Nois	se suppression system	For L-category vehicles powered by internal combustion engines, visual inspection and measurement of noise emitted by stationary vehicle using a sound level meter.	1	Х	
		For other vehicles, subjective evaluation			

8.2.	Exhaust emissions	(unless the inspector considers that the noise level may be borderline, in which case a measurement of noise emitted by stationary vehicle using a sound level meter may be conducted)		
8.2.1.	Exhaust emissions control equipment	Visual inspection complemented, where made possible by the technical characteristics of the vehicle and where the necessary data is made	(a) Emission control equipment fitted by the manufacturer absent, modified or obviously defective.	X
		available, with the use of electronic interface (OBD or OBM read-out)	(b) Leaks which would affect emission measurements.	X
			(c) Warning device malfunctioning, warning indicator / tell- tale inoperative.	X
			(d) MIL activated, warning device shows system malfunction.	X
			(e) System indicates failure via the electronic vehicle interface.	X
			(f) Exhaust emission control unit modified affecting safety and/or the environment.	Х
			(g) Any other emission relevant control unit modified affecting safety and/or the environment.	X
			(h) Presence of electronic devices not authorised by the vehicle manufacturer nor approved during homologation changing signals to or from the engine or pollution control unit(s).	X
			(i) OBD or OBM read-out indicating significant malfunction.	X

8.2.2 Exhaust emission measurement – positive ignition engines	Test procedures:			
ignition engines	For vehicles that had a particle number (PN) limit at type-approval; Euro VI, Euro 6c and newer:			
	Particle number measurement in accordance with 8.2.2.1.			
	For all vehicles:			
	Gaseous emissions test in accordance with 8.2.2.2.			
	For vehicles as of emission classes Euro VI, 6d- TEMP and newer:			
	$NO_X$ measurement in accordance with 8.2.2.3.			
8.2.2.1 Particle number measurement	Vehicle preparation:	Measurement result exceeds [to be specified in accordance with the delegated acts referred to in Article	Х	
	<ul> <li>[to be specified in accordance with the delegated acts referred to in Article 17]</li> </ul>	$17](1/cm^3)$		
	Measuring instrument preparation:			
	— The device to measure PN is powered on for at least the warm-up time indicated by the manufacturer;			
	— Self-checks of the instrument [to be specified in accordance with the delegated acts referred to in Article 17], to monitor the proper operation of the instrument during operation and trigger a warning or message in case of malfunction;			
	Before each test, the good condition of the sampling system shall be verified, including checking the sampling hose and probe for damage.			
	Test procedure:			
	— The software of the particle counter automatically guides the instrument operator through the test procedure;			
	— The probe is inserted at least 0,20 m into the outlet of the exhaust system. In justified			

possible, th	where sampling at this depth is not e probe is inserted at least 0,05 m. ng probe shall not touch the walls of		
outlet, the this case concentrati system ou	xhaust system has more than one est shall be done to all of them. In the highest measured PN on measured at different exhaust tlets shall be considered as the N concentration;		
accordance in Article 1 not switch start/stop sy operator.	ehicle operates [as specified in with the delegated acts referred to 7]. In case the engine of a vehicle is d on at static conditions then the stem shall be deactivated by the test For hybrid and plug-in hybrid e thermal engine shall be switched		
	e probe has been inserted into the following steps shall be followed:		
secon speed 2. After conce The d [XX] durati	the stabilisation period, the PN ntration emissions are measured. aration of the test shall be at least seconds (total measurement on) [to be specified in accordance he delegated acts referred to in		
instrument	ompletion of the test procedure, the reports (and stores) the PN on of the vehicle and a "PASS" or ssage:		
	st result is less than or equal to the instrument reports a "PASS"		
	st result is greater than the limit, the reports a "FAIL" message.		

8.2.2.2. Gaseous emissions	Measurement using an exhaust gas analyser in	(a) Either gaseous emissions exceed the specific levels	Х	
	accordance with the requirements <sup>1</sup> .	given by the manufacturer;		
	Measurements not applicable for two-stroke	(b) Or, if this information is not available, the CO emissions exceed,	Х	
	engines.	(i) for vehicles not controlled by an advanced emission control system,		
		— 4,5 %, or		
		- 3,5 % according to the date of first registration or use specified in requirements <sup>1</sup> .		
		(ii) for vehicles controlled by an advanced emission control system,		
		— at engine idle: 0,5 %		
		— at high idle: 0,3 % or — at engine idle: 0,3 % ( <sup>7</sup> )		
		— at high idle: 0,2 % or		
		— at engine idle: 0,2 % ( <sup>8</sup> )		
		— at high idle: 0,1 % according to the date of first registration or use specified in requirements <sup>1</sup> .		
		(c) Lambda coefficient outside the range $1 \pm 0.03$ or not in accordance with the manufacturer's specification;	X	
8.2.2.3. NO <sub>X</sub> measurement	Vehicle preparation:	Measurement result exceeds [NO <sub>X</sub> limit to be specified in accordance with the delegated acts referred to in	Х	
	[to be specified in accordance with the delegated acts referred to in Article 17];	Article 17].		
	- []			
	Measuring instrument preparation:			
	<ul> <li>[to be specified in accordance with the delegated acts referred to in Article 17 or combined with PN testing above];</li> </ul>			

— Self-checks of the instrument [to be specified in accordance with the delegated acts referred to in Article 17];	
Before each test, the good condition of the sampling system shall be verified, including shecking the sampling hose and probe for damage.	
Fest procedure:         — [to be specified in accordance with the	
delegated acts referred to in Article 17 or combined with PN testing above].	

8.2.3 Exhaust emission measurement compression ignition engines	- Test procedures:			
	For vehicles as of emission classes Euro 5b and Euro VI and newer:			
	Particle number (PN) measurement in accordance with 8.2.3.1			
	For vehicles up to emission classes Euro 5a and Euro V:			
	Opacity measurement in accordance with 8.2.3.2.			
	For vehicles equipped with particle filters, Member States may apply PN measurement in accordance with 8.2.3.1 instead of opacity measurement.			
	For vehicles as of emission classes Euro 6d-TEMP and Euro VI and newer:			
	$NO_X$ measurement in accordance with 8.2.3.3.			
8.2.3.1 Particle number measurement	Vehicle preparation:	Measurement result exceeds 250 000 (1/cm <sup>3</sup> )	Х	
	At the beginning of the test the vehicle's engine should be:	For vehicles up to emission class Euro 5a and Euro V, equipped with particle filters, Member States may apply a limit up to 1		
	— Hot, i.e., engine coolant temperature above 60 °C but preferably above 70 °C			
	— Conditioned, by operating for a period of time at low idling and/or performing stationary accelerations up to maximum 2 000 rpm engine speed or by driving. The recommended total conditioning time is at least 300 seconds.	000 000 (1/cm <sup>3</sup> )		
	During the test, the vehicle shall not be performing an active particulate filter regeneration.			
	A fast pass test is possible with engine coolant temperature below 60 °C. However, if the vehicle fails to pass the test, the test shall be repeated, and the vehicle should fulfil the requirements set for the engine coolant temperature and the conditioning.			
	Measuring instrument (as specified in Sections 3, 4, and 5 of Commission Recommendation (EU) 2023/688, as adopted on 20 March 2023) preparation:			

 The instrument is powered on for at least the warm-up time indicated by the manufacturer;

— Self-checks of the instrument as defined in Section 5 of Commission Recommendation (EU) 2023/688, as adopted on 20 March 2023, to monitor the proper operation of the instrument during operation and trigger a warning or message in case of malfunction;

Before each test, the good condition of the sampling system shall be verified, including checking the sampling hose and probe for damage.

Test procedure:

 The software of the particle counter automatically guides the instrument operator through the test procedure;

— The probe is inserted at least 0,20 m into the outlet of the exhaust system. In justified exemptions where sampling at this depth is not possible, the probe is inserted at least 0,05 m. The sampling probe shall not touch the walls of the tailpipe;

— If the exhaust system has more than one outlet, the test shall be done to all of them. In this case, the highest measured PN concentration measured at different exhaust system outlets shall be considered as the vehicle's PN concentration;

— The vehicle operates at low idling. In case the engine of a vehicle is not switched on at static conditions then the start/stop system shall be deactivated by the test operator. For hybrid and plug-in hybrid vehicles, the thermal engine shall be switched on;

— After the probe has been inserted into the tailpipe, the following steps shall be followed:

- A stabilization period of at least 15 seconds with the engine running at idle speed. Optionally, before the stabilization period 2-3 accelerations up to maximum 2 000 rpm engine speed are performed,
- 2. After the stabilisation period, the PN concentration emissions are measured. The duration of the test shall be at least 15 seconds (total measurement duration). The test result shall be the average PN concentration of the measurement duration. If the measured PN concentration is more than two times the limit, the measurement may stop immediately before waiting for 15 seconds to elapse. The test result shall be reported.

	After the completion of the test procedure, the instrument reports (and stores) the average PN concentration of the vehicle and a "PASS" or "FAIL" message: — If the test result is less than or equal to the limit, the instrument reports a "PASS" message. — If the test result is greater than the limit, the instrument reports a "FAIL" message.			
8.2.3.2. Opacity Vehicles registered or put into service before 1 January 1980 are exempted from this requirement	Exhaust gas opacity to be measured during free acceleration (no load from idle up to cut-off speed) with gear lever in neutral and clutch engaged and, if specified in accordance with the type-approval regulations, reading of OBD in accordance with the manufacturer's recommendations and other requirements. Vehicle preconditioning: 1. Vehicles may be tested without preconditioning, although for safety reasons checks should be made that the engine is warm and in a satisfactory mechanical condition.	in requirements <sup>1</sup> .	Х	

2. Precondition requirements:	(b) Where this information is not available or requirements <sup>1</sup> do not allow the use	
<ul> <li>(i) Engine shall be fully warm, for instance the engine oil temperature measured by a probe in the oil level dipstick tube to be at least 80 °C, or normal operating temperature if lower, or the engine block temperature measured by the level of infrared radiation to be at least an equivalent temperature. If, owing to the vehicle configuration, this measurement is impractical, the establishment of the engine's normal operating temperature may be made by other means, for example by the operation of the engine cooling fan.</li> <li>(ii) Exhaust system shall be purged by at least three free acceleration cycles or by an equivalent method.</li> </ul>	<ul> <li>of reference values,</li> <li>for naturally aspirated engines: 2,5 m<sup>-1</sup>,</li> <li>for turbo-charged engines: 3,0 m<sup>-1</sup>, or</li> <li>for vehicles identified in requirements<sup>1</sup> or first registered or put into service for the first time after the date specified in requirements<sup>1</sup>: 1,5 m<sup>-1</sup> (<sup>9</sup>) or 0,7 m<sup>-1</sup> (<sup>8</sup>)</li> </ul>	
<ol> <li>Test procedure:</li> <li>Engine and any turbocharger fitted, to be at idle before the start of each free acceleration cycle. For heavy-duty diesels, this means waiting for at least 10 seconds after the release of the throttle.</li> <li>To initiate each free acceleration cycle, the throttle pedal must be fully depressed quickly and continuously (in less than one second) but not violently, so as to obtain maximum delivery from the injection pump.</li> </ol>		

3. During each free acceleration cycle, the engine shall reach cut-off speed or, the speed specified by the manufacturer or, if this data is not available, then two thirds of the cut-off speed, before the throttle is released. This could be checked, for instance, by monitoring engine speed or by allowing a sufficient time to elapse between initial throttle depression and release, which in the case of vehicles of categories  $M_2$ ,  $M_3$ ,  $N_2$  and  $N_3$ , should be at least two seconds.

4. Vehicles shall only be failed if the arithmetic means of at least the last three free acceleration cycles are in excess of the limit value. This may be calculated by ignoring any measurement that departs significantly from the measured mean, or the result of any other statistical calculation that takes account of the scattering of the measurements. Member States may limit the number of test cycles.

5. To avoid unnecessary testing, Member States may fail vehicles which have measured values significantly in excess of the limit values after fewer than three free acceleration cycles or after the purging cycles. Equally to avoid unnecessary testing, Member States may pass vehicles which have measured values significantly below the limits after fewer than three free acceleration cycles or after the purging cycles.

Item	Method	Reasons for failure	Assessment of deficiencies		
	· · · ·		Minor	Major	Dangerou
8.2.3.3. NO <sub>X</sub> measurement	Vehicle preparation:	Measurement result exceeds 40 ppm		X	
	Prior to testing, the vehicle's exhaust aftertreatment system shall be warmed up, to the conditions that allow effective abatement of $NO_X$ emissions by the selective catalytic reduction (SCR) unit of the vehicle by at least a 5-minute drive or an equivalent method. Once the condition is reached, the vehicle shall not be turned off and the measurement shall be performed within 3 minutes for M <sub>1</sub> and N <sub>1</sub> vehicles and within 3.5 minutes for M <sub>2</sub> , M <sub>3</sub> , N <sub>2</sub> and N <sub>3</sub> vehicles. Where possible, the vehicle's readiness to be tested shall be ascertained by checking the indicator lamp on the dashboard or via the vehicle interface (OBD or OBM read-out).				
	During the test, the vehicle shall not be performing an active particulate filter regeneration.				
	Measuring instrument preparation:				
	— The device to measure NO <sub>X</sub> emissions is powered on for a least the warm-up time indicated by the manufacturer;				
	— Self-checks of the instrument [to be specified in accordance with the delegated acts referred to in Article 17] to monitor the proper operation of the instrument during operation and trigger a warning or message in case of malfunction;	g			
	Before each test, the good condition of the sampling system shall be verified, including checking the sampling hose and probe for damage.				
	Test procedure:				
	— The software of the $NO_X$ analyser automatically guides the instrument operator through the test procedure;				
	— The probe is inserted at least 0,20 m into the outlet of the exhaust system. In justified exemptions where sampling at this				

depth is not possible, the probe is inserted at least 0,05 m. The sampling probe shall not touch the walls of the tailpipe;	
- If the exhaust system has more than one outlet, the test shall be done to all of them. In this case, the highest measured NOx concentration measured at different exhaust system outlets shall be considered as the vehicle's NO <sub>x</sub> concentration;	
— The vehicle operates at low idling;	
— After the probe has been inserted into the tailpipe, the following steps shall be followed:	
<ol> <li>A stabilization period of at least 15 seconds with the engine running at idle speed.</li> <li>After the stabilisation period, the NO<sub>X</sub> concentration emissions are measured. The duration of the test shall be at least 15 seconds (total measurement duration). The test result shall be the average NO<sub>X</sub> concentration of the measurement duration.</li> </ol>	
After the completion of the test procedure, the instrument reports (and stores) the average NO <sub>X</sub> concentration of the vehicle and a "PASS" or "FAIL" message:	
— If the test result is less than or equal to the limit, the instrument reports a "PASS" message.	
— If the test result is greater than the limit, the instrument reports a "FAIL" message.	

(xxxiv) in the table, item 8.4.1, is replaced by the following:

8.4.1. Fluid leaks	Visual inspection	Any excessive fluid leak, other than water, likely to harm the environment or to pose a safety risk to other road users.	Х	
		Steady formation of drops that constitutes a very serious risk.		Х

?. ?

(xxxv) in the table, the following item 10 is added:

10. ELECTRONIC SAFETY S	SYSTEMS				
10.1. Cornering light		(a) System or any component missing		Х	
Description: during cornering, an extra headlamp is activated. Operates up to 40 km/h, for example	made possible by the technical characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
in accordance with UNECE-R 48 or UNECE-R 119.	use of electronic interface	(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.2 Adaptive cruise control Description: The system maintains	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
the vehicle's speed, depending on the preferred speed and distance to the vehicle in front.	characteristics of the vehicle and where the	(b) System or components damaged, or sensors obviously misaligned		Х	
		(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	

		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	X		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.3 Adaptive deflectors Description: Depending on the	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
vehicle's speed, the air deflectors are adjusted in order to improve driving	characteristics of the vehicle and where the necessary data is made available, with the use of electronic interface	(b) System or components damaged		Х	
stability.		(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	

		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.4 Airbag Description: In case of an accident, inflatable airbags reduce the risk of	Visual inspection complemented, where made possible by the technical characteristics of the vehicle and where the	(a) System or components (for example seat occupancy detection) obviously missing.		Х	
injury by their absorbing effect, for example in accordance with	necessary data is made available, with the use of electronic interface	(b) System or components damaged		Х	
UNECE-R 12; UNECE-R 14; or UNECE-R 16.		(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board			Х
		(g) System or components obviously not operating (for example not suitable with the vehicle)		Х	
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board			Х
10.5 Active Headrest Description: the system reduces the	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
danger of a whiplash injury in the event of a rear end collision by	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
	use of electronic interface	(c) Software version or -integrity incorrect		Х	

changing the position of the headrest				37	
towards the head.		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board			Х
		(g) System or components not operating, where applicable, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board			Х
10.6 Active hood Description: by automatically lifting		(a) System or any component missing		Х	
the bonnet, the system ensures a larger collapsible zone in the event		(b) System or components damaged		Х	
of an accident involving a pedestrian.	use of electronic interface	(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating (for example outdated), where applicable, or implausible operation		Х	

		(h) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.7 Automatic hold function Description: the system	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
independently holds the vehicle after stopping using the service brake	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
and/or parking brake and automatically releases them when	use of electronic interface	(c) Software version or -integrity incorrect		Х	
starting.		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.8 Automatic headlamp levelling Description: depending on the load	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
and (optional) pitch angle, the system regulates the headlamp's	characteristics of the vehicle and where the necessary data is made available, with the use of electronic interface	(b) System or components damaged		Х	
		(c) Software version or -integrity incorrect		Х	

vertical aim, for example in accordance with UNECE-R 121.		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.9 Automatic emergency braking system	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
Description: the system independently starts braking in order to avoid a collision with an obstacle	characteristics of the vehicle and where the necessary data is made available, with the use of electronic interface	(b) System or components damaged, or sensors obviously misaligned		Х	
or another road user, or to reduce the consequences of an inevitable		(c) Software version or -integrity incorrect		Х	
impact.		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х

		(g) System or components not operating, or implausible operative (for example audio components)		Х	
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.10 Anti-lock braking system Description: the system	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
automatically prevents wheel- locking during braking by selective reduction of the wheel brake force,	characteristics of the vehicle and where the necessary data is made available, with the use of electronic interface	(b) System or components (for example wheel speed sensor) damaged		Х	
for example in accordance with UNECE-R 13 and Regulation (EU)		(c) Software version or -integrity incorrect		Х	
2019/2144.		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(a) System or any component missing		Х	

		(b) System or components damaged		Х	
		(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
10.11 Automatic light	Visual inspection complemented, where	(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
Description: depending on the ambient brightness, the system	made possible by the technical characteristics of the vehicle and where the	Affecting safe operation of the vehicle		Х	
automatically switches on and off the driving light.	necessary data is made available, with the use of electronic interface	Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.12 Electro-mechanic power steering	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
Description: the supporting power for steering is generated by an electric motor.	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
	use of electronic interface	(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	

		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating (for example Power assistance not working), or implausible operation (for example inconsistency between the angle of the steering wheel and the angle of the wheels.)		Х	
		Steering affected			Х
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.13 Electronic four-wheel steering Description: two axles are steered,	Visual inspection complemented, where	(a) System or any component missing		Х	
with a steering angle greater than 3° on all steered wheels, for example in	made possible by the technical characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
accordance with UNECE-R 79 and Regulation (EU) 2019/2144.	use of electronic interface	(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	

		(h) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.14 Electronic damping Description: depending on the	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
driving situation, the rebound and compression stage of the shock	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
absorbers is adjusted by the system.	use of electronic interface	(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.15 Electronic brake system Description: a brake pedal sensor and/or pressure sensor records the braking request and calculates the	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
	made possible by the technical characteristics of the vehicle and where the necessary data is made available, with the use of electronic interface, or by road test.	(b) System or components damaged		Х	
optimal brake force for each wheel,		(c) Software version or -integrity incorrect		Х	

so that there is optimal activation of all wheel brakes.		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.16 Electronic stability program Description: the system stabilizes the vehicle or the complete vehicle	use of electronic interface	(a) System or any component (for example wheel speed sensors) missing		Х	
train in critical, dynamic driving situations, for example in accordance with Regulation (EU)		(b) System or components (for example wheel speed sensors) damaged		Х	
2019/2144 and UNECE-R 140.		(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х

		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.17 High beam assist Description: the system	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
automatically activates and deactivates the high beam according	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
to the driving situation and lighting conditions.	use of electronic interface	(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.18SpeedlimiterDescription:Whiledriving, the	Visual inspection complemented, where made possible by the technical	(a) System or any component missing (for example seals, plaques), or not fitted in accordance with the requirements.		Х	

system prevents exceeding a defined	characteristics of the vehicle and where the				
maximum speed. Relevant, if		(b) System or components damaged		Х	
mandatory, for example in accordance with UNECE-R 89 and Regulation (EU) 2019/2144.	use of electronic interface	(c) Software version or -integrity incorrect		Х	
Regulation (EC) 2017/2144.		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation (for example tampered or manipulated, or size of tyres not compatible with calibration parameters, or incorrect set speed, if checked).		Х	
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.19 Belt tensioner and belt force limiter Description: In the event of an	Visual inspection complemented, where made possible by the technical characteristics of the vehicle and where the	(a) System or any component missing, or not suitable with the vehicle		Х	
accident, the seat belt is tensioned to place the passengers in a setpoint	necessary data is made available, with the use of electronic interface	(b) System or components damaged		Х	
position and/or limits the belt force, electrically controlled and, thus,		(c) Software version or -integrity incorrect		Х	
limits the forces acting on the persons for example in accordance		(d) Wiring damaged		Х	
with UNECE-R 16 or UNECE-R 94.		(e) Warning device shows system malfunction.		Х	

			1		
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board			Х
		(g) System or components not operating, where applicable, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	X		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board			Х
10.20 Taillight switching Description: Depending on	Visual inspection complemented, where made possible by the technical characteristics of the vehicle and where the necessary data is made available, with the use of electronic interface	(a) System or any component missing		Х	
operating status and/or failure of the illuminants, lighting functions are		(b) System or components damaged		Х	
taken over by other luminaires.		(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	

		(h) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.21 Bending light Description: during cornering and	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
depending on the steering angle and speed, the light beam is swivelled	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
and/or an additional headlight is activated, for example in accordance	use of electronic interface	(c) Software version or -integrity incorrect		Х	
with UNECE-R 48; UNECE-R 98; UNECE-R 112; or UNECE-R 123.		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.22 Steering assist Description: depending on the	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
driving situation, the steering angle is automatically changed, without	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
intervention by the driver. Relevant if the steering intervention occurs at	use of electronic interface	(c) Software version or -integrity incorrect		Х	

a speed of more than 15 km/h, for example in accordance with		(d) Wiring damaged		Х	
UNECE-R 79.		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operative (for example audio components)		Х	
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.23 Height levelling Description: the system changes the		(a) System or any component missing		Х	
clearance between vehicle chassis and the road.		(b) System or components damaged		Х	
	use of electronic interface	(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	

		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.24 Emergency braking signal Description: during strong	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
deceleration, hazard warning lights and/or additional luminous surfaces	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
are activated and/or the following traffic is warned by flashing brake	use of electronic interface	(c) Software version or -integrity incorrect		Х	
lights, for example in accordance with UNECE-R 48 or UNECE-R 13.		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(f) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.25 Pre-crash system Description: in a critical driving	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
situation, the vehicle is prepared for the crash so that the risk of injury to	characteristics of the vehicle and where the necessary data is made available, with the use of electronic interface	(b) System or components damaged		Х	
		(c) Software version or -integrity incorrect		Х	

				1	
the passengers and/or other road users is reduced.		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation (for example power windows)		Х	
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.26 Tyre pressure warning Description: the system detects loss	Visual inspection complemented, where made possible by the technical characteristics of the vehicle and where the necessary data is made available, with the	(a) System or any component missing		Х	
of tyre pressure through integrated sensors and/or by implausible values		(b) System or components damaged		Х	
for wheel speed, for example in accordance with Regulation (EU)	use of electronic interface	(c) Software version or -integrity incorrect		Х	
2019/2144 and UNECE-R 141.		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	

		(h) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.27 Traction control Description: the system prevents the	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
drive wheels spinning during acceleration by applying brake	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
force.	use of electronic interface	(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	X		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.28 Superimposed steering Description: depending on the	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
driving situation, the system varies the transmission ratio of the steering.	characteristics of the vehicle and where the necessary data is made available, with the use of electronic interface	(b) System or components damaged		Х	
		(c) Software version or -integrity incorrect		Х	

			r		
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating (for example power assistance not working), or implausible operation (for example inconsistency between the angle of the steering wheel and the angle of the wheels.)		Х	
		Steering affected			Х
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.29 Roll over protection (active) Description: in the event of an	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
imminent rollover, support elements are extended to secure the survival	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
space, for example in accordance with Regulation (EU) 2019/2144	use of electronic interface	(c) Software version or -integrity incorrect		Х	
and UNECE-R 21.		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х

	(g) System or components not operating, or implausible operation		Х	
	(h) Other failure Not affecting the safe operation	х		
	Affecting safe operation of the vehicle		Х	
	Danger to health of persons on board or of other road users			Х
isual inspection complemented, where nade possible by the technical	(a) System or any component missing		Х	
haracteristics of the vehicle and where the ecessary data is made available, with the	(b) System or components damaged		Х	
se of electronic interface	(c) Software version or -integrity incorrect		Х	
	(d) Wiring damaged		Х	
	(e) Warning device shows system malfunction.		Х	
	(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	х		
	Affecting safe operation of the vehicle		Х	
	Danger to health of persons on board or of other road users			Х
	(g) System or components not operating, or implausible operation		Х	
	(h) Other failure Not affecting the safe operation	Х		
	Affecting safe operation of the vehicle		Х	
	Danger to health of persons on board or of other road users			Х
isual inspection complemented, where nade possible by the technical	(a) System or any component missing		Х	
haracteristics of the vehicle and where the	(b) System or components damaged		Х	
nao ha ecc se	de possible by the technical racteristics of the vehicle and where the essary data is made available, with the of electronic interface ual inspection complemented, where de possible by the technical	ual inspection complemented, where the searcy data is made available, with the of electronic interface       (a) System or any component missing         (b) System or any component missing       (c) Software version or -integrity incorrect         (d) Wiring damaged       (e) Warning device shows system malfunction.         (f) System or components failure via the electronic vehicle interface       (f) System or components during device shows system malfunction.         (f) System or components failure via the electronic vehicle interface       (f) System indicates failure via the electronic vehicle interface         (g) System or components not operating, or implausible operation       (h) Other failure         (h) Other failure       Not affecting safe operation         (h) System or components not operating, or implausible operation       (h) Other failure         (h) Other failure       Not affecting safe operation         (h) System or components not operating, or implausible       (h) Other failure         (h) Other failure       Not affecting safe operation         (h) System or any component missing       (a) System or any component missing	(h) Other failure       X         Affecting safe operation       X         Affecting safe operation of the vehicle       Danger to health of persons on board or of other road users         ual inspection complemented, where the of electronic interface       (a) System or any component missing         (b) System or components damaged       (c) Software version or -integrity incorrect       (d)         (d) Wiring damaged       (e) Warning device shows system malfunction.       (f) System indicates failure via the electronic vehicle interface         Not affecting safe operation of the vehicle       Danger to health of persons on board or of other road users       X         (f) System indicates failure via the electronic vehicle interface       X       Affecting safe operation       X         (g) System or components not operating, or implausible operation       (h) Other failure       X       Affecting safe operation       X         (h) Other failure for the safe operation of the vehicle       Danger to health of persons on board or of other road users       X         (g) System or components not operating, or implausible operation       X       X         Affecting safe operation of the vehicle       Danger to health of persons on board or of other road users       X         (h) Other failure for the safe operation       X       X       Affecting safe operation       X         Affecting safe operation of the vehi	Image: Construction of the state operation in the vehicle interface is the state operation of the vehicle interface is the state operation of the vehicle interface is the state operation of the vehicle interface is the vehicle and where the searcy data is made available, with the of electronic interface is the vehicle and where the searcy data is made available, with the of electronic interface is the vehicle and where the searcy data is made available, with the of electronic interface is the vehicle and where the searcy data is made available, with the of electronic interface is the vehicle and where the searcy data is made available, with the of electronic interface is the vehicle and the vehicle interface is the vehicle and the vehicle interface is the vehicle and the vehicle interface is the state operation of the vehicle interface is the state operation of the vehicle interface is the vehicle is the state operation of the vehicle interface is the vehicle is the state operation of the vehicle is the state operation is the state operation is the state operation is the vehicle is t

momentarily applying brake pressure or by automatic release of		(c) Software version or -integrity incorrect		Х	
the parking brake.		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	X		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.32 Trailer stabilization Description: through selective	Visual inspection complemented, where made possible by the technical characteristics of the vehicle and where the necessary data is made available, with the	(a) System or any component missing		Х	
braking of the trailer by the service brakes, the complete vehicle train is		(b) System or components damaged		Х	
stabilised.	use of electronic interface	(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х

		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.33 Endurance brake Description: an additional braking system that can maintain braking	Visual inspection (with command activated and not activated, if possible) complemented, where made possible by	(a) System or any component missing (for example Insecure connectors or mountings)		Х	
over a period of time without a significant reduction in	the technical characteristics of the vehicle and where the necessary data is made	(b) System or components damaged		Х	
performance, for example in accordance with UNECE-R 13 and	available, with the use of electronic	(c) Software version or -integrity incorrect		Х	
Regulation (EU) 2019/2144.		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(j) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(a) System or any component missing		Х	

			1		
		(b) System or components damaged		Х	
		(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	х		
10.34 Differential lock deactivation Description: when this system is	Visual inspection complemented, where	Affecting safe operation of the vehicle		Х	
activated, the differential locks are unlocked depending on parameters	made possible by the technical characteristics of the vehicle and where the	Danger to health of persons on board or of other road users			Х
(for example wheel slip, steering angle, speed).	necessary data is made available, with the use of electronic interface	(g) System or components not operating, or implausible operation		Х	
		Steering affected			Х
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			х
10.35 Electronically controlled leading and trailing axle	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
Description: the steered axles are additional axles with electronically	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
controlled steering. The steering force is generated by a hydraulic	use of electronic interface	(c) Software version or -integrity incorrect		Х	
pump or by the lateral force on the wheels.		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	

		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	X		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		Steering affected			Х
		(h) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.36 Electronic steering damper Description: Steering damping is	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
controlled electronically.	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
	use of electronic interface	(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х

		(g) System or components not operating, or implausible operation		Х	
		Steering affected			х
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.37 Bus stop brake Description: the system ensures the	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
application of brake pressure when stationary, independent of the brake	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
pedal activation. Buses can only start moving when the doors are	use of electronic interface	(c) Software version or -integrity incorrect		Х	
closed.		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х

Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
use of electronic interface	(c) Software version or -integrity incorrect		Х	
	(d) Wiring damaged		Х	
	(e) Warning device shows system malfunction.		Х	
	(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
	Affecting safe operation of the vehicle		Х	
	Danger to health of persons on board or of other road users			Х
	(g) System or components not operating, or implausible operation		Х	
	(h) Other failure Not affecting the safe operation	Х		
	Affecting safe operation of the vehicle		Х	
	Danger to health of persons on board or of other road users			Х
Visual inspection complemented, where	(a) System or any component missing		Х	
characteristics of the vehicle and where the	(b) System or components damaged		Х	
use of electronic interface	(c) Software version or -integrity incorrect		Х	
	(d) Wiring damaged		Х	
	(e) Warning device shows system malfunction.		Х	
	made possible by the technical characteristics of the vehicle and where the necessary data is made available, with the use of electronic interface Visual inspection complemented, where made possible by the technical characteristics of the vehicle and where the necessary data is made available, with the	madepossiblebythetechnical data is made available, with the use of electronic interface(b) System or components damaged(c) Software version or - integrity incorrect(d) Wiring damaged(e) Warning device shows system malfunction.(f) System indicates failure via the electronic vehicle interface Not affecting safe operationAffecting safe operationAffecting safe operation(g) System or components not operating, or implausible operation(h) Other failure Not affecting the safe operation(h) Other failure Not affecting the safe operation(h) Other failure Not affecting safe operation of the vehicleDanger to health of persons on board or of other road users(g) System or components not operating, or implausible operation(h) Other failure Not affecting safe operation of the vehicleDanger to health of persons on board or of other road users(i) System or any component missing (b) System or components damaged(c) Software version or -integrity incorrect(d) Wiring damaged	made possible by the technical characteristics of the vehicle and where the necessary data is made available, with the use of electronic interface       (b) System or components damaged         (c) Software version or -integrity incorrect       (d) Wiring damaged         (e) Warning device shows system malfunction.       (f) System indicates failure via the electronic vehicle interface         (f) System indicates failure via the electronic vehicle interface       X         Affecting safe operation of the vehicle       Danger to health of persons on board or of other road users         (g) System or components not operating, or implausible operation       X         Affecting safe operation of the vehicle       Danger to health of persons on board or of other road users         (g) System or components not operating, or implausible operation       X         Affecting safe operation of the vehicle       Danger to health of persons on board or of other road users         Visual inspection complemented, where made possible by the technical characteristics of the vehicle and where the necessary data is made available, with the use of electronic interface       (a) System or components damaged         (c) Software version or -integrity incorrect       (d) Wiring damaged       (c) Software version or -integrity incorrect	made possible by the technical characteristics of the vehicle and where the necessary data is made available, with the use of electronic interface       (b) System or components damaged       X         (c) Software version or -integrity incorrect       X         (d) Wiring damaged       X         (e) Warning device shows system malfunction.       X         (f) System or components damaged       X         (e) Warning device shows system malfunction.       X         (f) System or components not operation       X         (g) System or components not operation, or implausible       X         (g) System or components not operating, or implausible       X         (h) Other failure       X         Not affecting safe operation of the vehicle       X         (h) Other failure       X         Not affecting safe operation of the vehicle       X         Affecting safe operation of the vehicle       X         Not affecting safe operation of the vehicle       X         Not affecting safe operation of the vehicle       X         Danger to health of persons on board or of other road users       X         (h) Other failure       X         Not affecting safe operation of the vehicle       X         Danger to health of persons on board or of other road users       X         (b) System or component missin

		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		х	
		Steering affected			Х
		(h) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.40 Tyre pressure control Description: according to the	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
requirement of the driver, the system regulates the tyre pressure.	characteristics of the vehicle and where the necessary data is made available, with the use of electronic interface	(b) System or components damaged		Х	
8		(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	

		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.41 Sliding joint stabilisation Description: The articulated joint is	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
stabilised by damping, depending on vehicle speed, cylinder pressure of	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
the articulated dampers, steering and articulation-angle.	use of electronic interface	(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.42 Four-wheel parking brake Description: the system applies the	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
maximum brake pressure in the wheel cylinders at all four wheels.	characteristics of the vehicle and where the necessary data is made available, with the use of electronic interface	(b) System or components damaged		Х	
		(c) Software version or -integrity incorrect		Х	

		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.43 Front-wheel locking device Description: front wheel suspension,	Visual inspection complemented, where made possible by the technical characteristics of the vehicle and where the necessary data is made available, with the use of electronic interface	(a) System or any component missing		Х	
which permits lateral inclination of the motorcycle, can be locked and		(b) System or components damaged		Х	
unlocked by an electric actuator. Above a certain speed, it is		(c) Software version or -integrity incorrect		Х	
automatically unlocked.		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	

		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.44 Adaptive headlights Description: the illumination of the	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
surrounding road area and/or the direct illumination of road users in	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
the danger area in front of the vehicle is optimised by dynamic	use of electronic interface	(c) Software version or -integrity incorrect		Х	
adaption of the light beams.		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.45 Electrically actuated parking brake	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
Description: the parking brake function is triggered or transmitted	made possible by the technical characteristics of the vehicle and where the necessary data is made available, with the use of electronic interface	(b) System or components damaged		Х	
		(c) Software version or -integrity incorrect		Х	

1					
electronically or electromechanically.		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.46 Lane change assistance Description: at a lane change, the	made possible by the technical characteristics of the vehicle and where the	(a) System or any component missing		Х	
system warns the driver about vehicles in the next lane and steers		(b) System or components damaged		Х	
the vehicle back.		(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	

		(h) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.47 Lane keeping assistance Description: the system warns the	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
driver when the vehicle is unintentionally leaving its lane and	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
steers the vehicle back, e.g. in accordance with Regulation (EU)	use of electronic interface	(c) Software version or -integrity incorrect		Х	
2019/2144 and Commission Implementing Regulation (EU) 2021/646*.		(d) Wiring damaged		Х	
2021/040*.		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.48 Automatic eCall	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
Description: the system is triggered automatically by in-vehicle sensors or manually, it transmits a minimum	made possible by the technical characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
set of data (EN 15722) via mobile communication network and	use of electronic interface	(c) Software version or -integrity incorrect		Х	

establishes an audio connection based on the (emergency) number		(d) Wiring damaged		Х	
between the vehicle passengers and the public safety answering point, in	The verification of the minimum set of data (MSD) includes checking whether:	(e) Warning device (eCall MIL) shows system malfunction.		Х	
accordance with Regulation (EU) 2015/758 of the European Parliament and of the Council**, and Commission Delegated	<ul> <li>the mandatory fields are filled with plausible information;</li> <li>the deviation between in-vehicle</li> </ul>	(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
Regulation (EU) 2017/79***.	system (IVS) location and true location is less than 150 meters. The calculation can be done	Affecting safe operation of the vehicle		Х	
	according to point 2.5 of Annex I of Commission Delegated	Danger to health of persons on board			Х
	Regulation (EU) 2017/79; - the deviation between the MSD	(g) System or components not operating, or implausible operation:		Х	
	timestamp and the timestamp of the reading is less than 60s.	- audio components (for example failing echo-test);			
		- minimum set of data incorrect			
		(h) Other failure (for example mobile network communication device, electronic control unit, or GPS signal failure) Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board			Х
10.49 Active roll stabilisation Description: via appropriate	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
actuators the system produces a roll movement which counters the	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
vehicle's body roll movement depending on the current driving	use of electronic interface	(c) Software version or -integrity incorrect		Х	
situation.		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х

		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
generates at least a part of the	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
	use of electronic interface	(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
	characteristics of the vehicle and where the	(b) System or components damaged		Х	

specific sound in order to warn, for	necessary data is made available, with the	(c) Software version or -integrity incorrect		х	
example pedestrians.	use of electronic interface	(c) software version of -integrity incorrect		Л	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	x		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operative, or not respecting type-approved noise levels		Х	
		(h) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.52 Basic exterior lights Description: the system switches	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
on/switches off the basic lighting devices (for example indicators).	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
	use of electronic interface	(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х

					· · · · · · · · · · · · · · · · · · ·
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
	isual inspection complemented, where ade possible by the technical	(a) System or any component missing		Х	
Description: a system which is char	are possible by the technical paracteristics of the vehicle and where the eccessary data is made available, with the	(b) System or components damaged		Х	
keeps the vehicle within its lane by use controlling the lateral and	e of electronic interface	(c) Software version or -integrity incorrect		Х	
longitudinal movements of the vehicle for extended periods without		(d) Wiring damaged		Х	
the need for further driver input (for example in accordance with UNECE-R 157).		(e) Warning device shows system malfunction.		Х	
in accordance with ONLEEL-K 157).		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
	isual inspection complemented, where ade possible by the technical	(a) System or any component missing		Х	
	aracteristics of the vehicle and where the	(b) System or components damaged		Х	

traffic participant (for example	necessary data is made available, with the			N/	
bicycle) near side (for example in	use of electronic interface	(c) Software version or -integrity incorrect		Х	
accordance with UNECE-R 151).		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.55 Tachograph Description: a system to record the driving time, breaks, rest periods as well as periods of other work	Visual inspection complemented, where made possible by the technical characteristics of the vehicle and where the necessary data is made available, with the	(a) System or any component missing (for example seals, plaques), or not fitted in accordance with the requirements (for example plaque out of date).		Х	
undertaken by a driver, for example, in accordance with Regulation (EU) No 165/2014 of the European	use of electronic interface	(b) System or components damaged (for example illegible plaque)		Х	
Parliament and of the Council****.		(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	

		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation (for example tampered or manipulated, or size of tyres not compatible with calibration parameters, or incorrect set speed, if checked).		Х	
		(h) Other failure Not affecting the safe operation	Х		
	Visual inspection complemented, where made possible by the technical characteristics of the vehicle and where the necessary data is made available, with the	Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.56 Intelligent speed assistance Description: system to aid the driver		(a) System or any component missing		Х	
in maintaining the appropriate speed for the road environment by		(b) System or components damaged		Х	
providing dedicated and appropriate feedback, for example in accordance	use of electronic interface	(c) Software version or -integrity incorrect		Х	
with Regulation (EU) 2019/2144 and Commission Delegated Regulation (EU) 2021/1958*****.		(d) Wiring damaged		Х	
Regulation (EU) 2021/1938		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	

		(g) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.57 Reversing detection Description: system to make the	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
driver aware of people and objects at the rear of the vehicle with the	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
primary aim of avoiding collisions when reversing, for example in	use of electronic interface	(c) Software version or -integrity incorrect		Х	
accordance with Regulation (EU) 2019/2144 and UNECE-R 158.		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.58 Driver drowsiness and attention warning	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
Description: system that assesses the driver's alertness through vehicle	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
systems analysis and warns the driver if needed, for example in	use of electronic interface	(c) Software version or -integrity incorrect		Х	

accordance with Regulation (EU) 2019/2144 and Commission		(d) Wiring damaged		Х	
Delegated Regulation (EU) 2021/1341*****.		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.59 Advanced driver distraction warning	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
Description: system that helps the driver to continue to pay attention to	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
the traffic situation and that warns the driver when he or she is	use of electronic interface	(c) Software version or -integrity incorrect		Х	
distracted, for example in accordance with Regulation (EU)		(d) Wiring damaged		Х	
2019/2144 and Commission Delegated Regulation (EU) 2023/2590******		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	

		-			
		(h) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.60 Event data recorder Description: system with the only	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
purpose of recording and storing critical crash-related parameters and	characteristics of the vehicle and where the necessary data is made available, with the use of electronic interface	(b) System or components damaged		Х	
information shortly before, during and immediately after a collision, for		(c) Software version or -integrity incorrect		Х	
example in accordance with Regulation (EU) 2019/2144, Commission Delegated Regulation		(d) Wiring damaged		Х	
(EU) 2022/545*******, and UNECE-R 160.		(e) Warning device shows system malfunction.		Х	
UNECE-K 100.		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		(g) System or components not operating, or implausible operation (for example data not accessible)		Х	
		(h) Other failure Not affecting the safe operation	Х		
10.61 Automated driving system	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
Description: systems that are capable of performing the entire dynamic driving task of the fully automated vehicle on a sustained basis, for example in accordance	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
	use of electronic interface	(c) Software version or -integrity incorrect		Х	
with Regulation (EU) 2019/2144 and Commission Implementing Regulation (EU)		(d) Wiring damaged		Х	
Regulation (EU) 2022/1426*******.		(e) Warning device shows system malfunction.		Х	

		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation (for example HMI)		Х	
		(h) Other failure Not affecting the safe operation	X		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.62 Driver availability monitoring systems (automated driving)	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
systems (automated driving) Description: System that assesses whether the driver is capable of	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
taking over the driving function of a self-driving vehicle, if necessary, in	use of electronic interface	(c) Software version or -integrity incorrect		Х	
certain situations, for example in accordance with Regulation (EU)		(d) Wiring damaged		Х	
2019/2144 and UNECE-R 157.		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation (for example HMI)		Х	

	(h) Other failure Not affecting the safe operation	Х		
	Affecting safe operation of the vehicle		Х	
	Danger to health of persons on board or of other road users			х

**\*\*** Regulation (EU) 2015/758 of the European Parliament and of the Council of 29 April 2015 concerning type-approval requirements for the deployment of the eCall in-vehicle system based on the 112 service and amending Directive 2007/46/EC (OJ L 123, 19.5.2015, p. 77, ELI: <u>http://data.europa.eu/eli/reg/2015/758/oj).</u>

\*\*\*\*\* Commission Delegated Regulation (EU) 2021/1958 of 23 June 2021 supplementing Regulation (EU) 2019/2144 of the European Parliament and of the Council by laying down detailed rules concerning the specific test procedures and technical requirements for the type-approval of motor vehicles with regard to their intelligent speed assistance systems and for the type-approval of those systems as separate technical units and amending Annex II to that Regulation (OJ L 409, 17.11.2021, p. 1, ELI: http://data.europa.eu/eli/reg\_del/2021/1958/oj).

\*\*\*\*\* Commission Delegated Regulation (EU) 2021/1341 of 23 April 2021 supplementing Regulation (EU) 2019/2144 of the European Parliament and of the Council by laying down detailed rules concerning the specific test procedures and technical requirements for the type-approval of motor vehicles with regard to their driver drowsiness and attention warning systems and amending Annex II to that Regulation (OJ L 292, 16.8.2021, p. 4, ELI: <u>http://data.europa.eu/eli/reg\_del/2021/1341/oj</u>).

\*\*\*\*\*\* Commission Delegated Regulation (EU) 2023/2590 of 13 July 2023 supplementing Regulation (EU) 2019/2144 of the European Parliament and of the Council by laying down detailed rules concerning the specific test procedures and technical

<sup>\*</sup> Commission Implementing Regulation (EU) 2021/646 of 19 April 2021 laying down rules for the application of Regulation (EU) 2019/2144 of the European Parliament and of the Council as regards uniform procedures and technical specifications for the type-approval of motor vehicles with regard to their emergency lane-keeping systems (ELKS) (OJ L 133, 20.4.2021, p. 31, ELI: <u>http://data.europa.eu/eli/reg\_impl/2021/646/oj</u>).

<sup>\*\*\*</sup> Commission Delegated Regulation (EU) 2017/79 of 12 September 2016 establishing detailed technical requirements and test procedures for the EC type-approval of motor vehicles with respect to their 112-based eCall in-vehicles systems, of 112-based eCall in-vehicle separate technical units and components and supplementing and amending Regulation (EU) 2015/758 of the European Parliament and of the Council with regard to the exemptions and applicable standards (OJ L 12, 17.1.2017, p. 44, ELI: http://data.europa.eu/eli/reg\_del/2017/79/oj).

<sup>\*\*\*\*</sup> Regulation (EU) No 165/2014 of the European Parliament and of the Council of 4 February 2014 on tachographs in road transport, repealing Council Regulation (EEC) No 3821/85 on recording equipment in road transport and amending Regulation (EC) No 561/2006 of the European Parliament and of the Council on the harmonisation of certain social legislation relating to road transport (OJ L 60, 28.2.2014, p. 1, ELI: <u>http://data.europa.eu/eli/reg/2014/165/oj</u>).

requirements for the type-approval of certain motor vehicles with regard to their advanced driver distraction warning systems and amending that Regulation (OJ L, 2023/2590, 22.11.2023, ELI: <u>http://data.europa.eu/eli/reg\_del/2023/2590/oj</u>).

\*\*\*\*\*\*\* Commission Delegated Regulation (EU) 2022/545 of 26 January 2022 supplementing Regulation (EU) 2019/2144 of the European Parliament and of the Council by laying down detailed rules concerning the specific test procedures and technical requirements for the type-approval of motor vehicles with regard to their event data recorder and for the type-approval of those systems as separate technical units and amending Annex II to that Regulation (OJ L 107, 6.4.2022, p. 18, ELI: http://data.europa.eu/eli/reg\_del/2022/545/oj).

\*\*\*\*\*\*\* Commission Implementing Regulation (EU) 2022/1426 of 5 August 2022 laying down rules for the application of Regulation (EU) 2019/2144 of the European Parliament and of the Council as regards uniform procedures and technical specifications for the type-approval of the automated driving system (ADS) of fully automated vehicles (OJ L 221, 26.8.2022, p. 1, ELI: <u>http://data.europa.eu/eli/reg\_impl/2022/1426/oj).</u>

';

(2) Annex III is amended as follows:

(a) in section I 'Facilities and equipment', the first paragraph is amended as follows:

(i) points (9) and (10) are replaced by the following:

(9) A Class II sound level meter, if sound level is measured;

(10) A 4-gas analyser in accordance with Directive 2014/32/EU of the European Parliament and of the Council\*;

\* Directive 2014/32/EU of the European Parliament and of the Council of 26 February 2014 on the harmonisation of the laws of the Member States relating to the making available on the market of measuring instruments (OJ L 96, 29.3.2014, p. 149, ELI: http://data.europa.eu/eli/dir/2014/32/oj).';

(ii) the following points (16) and (17) are added:

(16) device to measure particle number emissions with sufficient accuracy;

(17) [From one year after the entry into force of the delegated act referred to in Article 17], a device to measure nitrogen oxide ( $NO_X$ ) emissions.';

# (b) in section II, Table I is replaced by the following:

#### •*Table I* (\*)

Vehicle	25	Category	r						Equ	ipment re	equired f	for each i	tem liste	d in sect	tion I					
	Maximum mass			1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1. Motorcycles			1																	
		L1e	Р	x								х	x		x	х	x			
		L3e, L4e	Р	х								X	x		x	X	х			
		L3e, L4e	D	x								x		х	x	x	x			
		L2e	Р	x	x							x	x		x	х	x			
		L2e	D	x	х							x		х	x	x	х			
		L5e	Р	x	х							x	x		x	x	x			
		L5e	D	х	х							х		х	x	х	x			
		L6e	Р	x	х							x	х		x	x	х			
		L6e	D	x	x							x		х	x	х	x			
		L7e	Р	x	х							х	x		х	x	х			
		L7e	D	x	x							x		x	x	x	x			

Minimum equipment required for the purpose of performing a roadworthiness test

|--|

Vehicles		Category							Equi	pment re	equired fo	or each i	em liste	d in sect	ion I					
	Maximum mass			1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
	Up to 3 500 kg	M1, M2	Р	x	x		x					x	x		x	x	x	x	x	x
	Up to 3 500 kg	M1, M2	D	x	х		х					х		х	х	x	х		x	Х
	> 3 500 kg	M <sub>2</sub> , M <sub>3</sub>	Р	x	х	x		х	х	х	х	х	х		х	x	х	x	x	х
	> 3 500 kg	M <sub>2</sub> , M <sub>3</sub>	D	x	x	x		x	х	х	х	х		х	х	x	x		x	х
3. Vehicles for the carriage of goods																				
	Up to 3 500 kg	$N_1$	Р	х	x		x					х	х		х	х	х	x	x	х
	Up to 3 500 kg	N1	D	х	х		х					х		х	х	х	х		х	Х
	> 3 500 kg	N <sub>2</sub> , N <sub>3</sub>	Р	x	х	x		x	х	х	х	х	х		х	x	х	x	x	х
	> 3 500 kg	N <sub>2</sub> , N <sub>3</sub>	D	x	х	x		х	х	х	х	х		х	х	x	х		x	Х
<ul> <li>▲<u>M1</u> Special vehicles derived from a category N vehicle, T1b, T2b, T3b, T4.1b, T4.2b and T4.3b </li> </ul>																				
	Up to 3 500 kg	<b>N</b> 1	Р	x	x		x					х	х		х	x	x	x	x	х
	Up to 3 500 kg	N1	D	x	x		x					х		x	x	x	x		х	х

Vehic	les	Category							Equi	pment re	equired f	òr each i	tem liste	d in sect	ion I					
	Maximum mass			1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
	> 3 500 kg	N <sub>2</sub> , N <sub>3</sub> , $\blacktriangleright M1$ T1b, T2b, T3b, T4.1b, T4.2b and T4.3b $\blacktriangleleft$	р	X	X	X		x	х	X	X	x	X		X	x	x	x	x	x
	> 3 500 kg	N <sub>2</sub> , N <sub>3</sub> , $\blacktriangleright M1$ T1b, T2b, T3b, T4.1b, T4.2b and T4.3b $\blacktriangleleft$	D	x	x	x		x	х	х	x	x		x	x	x	x		x	X
5. Trailers	Up to 750 kg	O1		х												х				
	> 750 to 3 500 kg	O <sub>2</sub>		x	x		x									х				
	> 3 500 kg	O <sub>3</sub> , O <sub>4</sub>		х	х	х			х	х	х					х				

\* The vehicle categories which are outside the scope of this Directive are included for guidance.

<sup>1</sup> P...petrol (positive ignition); D...diesel (compression ignition)

';

## (3) In Annex IV, in point 2, point (a), points (i) and (ii) are replaced by the following:

- '(i) vehicle technology:
- braking systems;
- steering systems;
- fields of vision;
- light installation, lighting equipment and electronic components;
- axles, wheels and tyres;
- chassis and bodywork;
- nuisance and emissions;
- alternative drives (high-voltage, hybrid, hydrogen systems);
- additional requirements for special vehicles;

(ii) testing methods (including the necessary training for inspecting vehicles equipped with high-voltage systems);'.

# ANNEX 🛄

Annexes II, III, IV and V to Directive 2014/47/EU are amended as follows:

- (1) Annex II is amended as follows:
- (a) in point 1, the following point (10) is added:

'(10) Electronic safety systems.';

(b) point 3 is amended as follows:

۷

(i) the heading is replaced by the following:

'3. CONTENTS AND METHODS OF TESTING, REASONS FOR FAILURE, AND ASSESSMENT OF DEFICIENCIES OF VEHICLES';

(ii) in the table, items 1.1.3 to 1.1.6 are replaced by the following:

1.1.3. Vacuum pump or compressor and reservoirs	Visual inspection of the components at normal working pressure. Check time required for vacuum or air pressure to reach safe working value and function of warning device, multi-circuit protection valve and pressure relief valve.	<ul> <li>(a) Insufficient pressure/vacuum to give assistance for at least four brake applications after the warning device has operated (or gauge shows an unsafe reading);</li> <li>at least two brake applications after the warning device has operated (or gauge shows an unsafe reading).</li> </ul>		Х	X
	Brake application means depression of the brake pedal/lever which allows the full flow of air/fluid application pressure to the brake assemblies.	(b) Time taken to build up air pressure/vacuum to safe working value is too long according to the require- ments <sup>1</sup>		Х	
		(c) Multi-circuit protection valve or pressure relief valve not working.		Х	
		(d) Air leak causing a noticeable drop in pressure or audible air leaks.		Х	
		Air leak causing a critical drop in pressure.			Х
		(e) External damage likely to affect the function of the braking system.		Х	
1.1.4. Low pressure warning device	Functional check	Malfunctioning or defective warning device.	Х		
		Low pressure not identifiable.		Х	
1.1.5. Hand-operated brake control valve	Visual inspection of the components while	(a) Control cracked, damaged or excessively worn.		Х	
	the braking system is operated.	(b) Control insecure on valve or valve insecure.		Х	
		(c) Loose connections, defective fixing, or leaks in system.		Х	
		(d) Unsatisfactory operation.		Х	

control, parking brake ratchet) the braking system is operated.	the braking system is operated.	(a) Ratchet not holding correctly.		Х	
		(b) Wear at lever pivot or in ratchet mechanism.	Х		
		Excessive wear.		Х	
	(c) Excessive movement of lever indicating incorrect adjustment.		Х		
		(d) Activator missing, damaged or inoperative.		Х	
		(e) Incorrect functioning, warning indicator shows malfunction		Х	

6

(iii) in the table, item 1.1.13 is replaced by the following:

1.1.13.	Brake linings and pads	Visual inspection.	(a) Lining or pad excessively worn (minimum mark reached).	Х	
			Lining or pad excessively worn (minimum mark not visible).		Х

(b) Lining or pad contaminated (oil, grease etc.).		Х	
Braking performance affected.			Х
(c) Lining or pad missing or wrongly mounted, or of obviously incorrect type.			Х
(d) Wear indicator electrical harness disconnected or damaged	Х		

6

(iv) in the table, item 1.1.18 is replaced by the following:

1.1.18.	1.1.18. Slack adjusters and indicators	Visual inspection of the components while the braking system is operated, if possible.	(a) Adjuster damaged, seized or having abnormal movement, excessive wear, or incorrect adjustment.	Х	
			(b) Adjuster defective.	Х	
			(c) Incorrectly installed or replaced.	Х	

(v) in the table, item 1.1.19 is deleted;

;

6

';

(vi) in the table, item 1.1.23 is replaced by the following:

1.1.23. Overrun brake	Visual inspection and by operation	(a) Not working properly, for example, stroke of the drawbar exceeds 2/3 of the total overrun travel	Х	
		(b) Breakaway cable defect or missing	Х	

(vii) in the table, items 1.2.1 and 1.2.2 are replaced by the following:

1.2.1.	Performance (E)	During a test on a brake tester or, if impossible, during a road test, apply the brakes progressively up to maximum effort. It must be ensured, where possible, that the mechanical service brakes are inspected without interference/blending of regenerative braking or other continuous braking.	<ul> <li>(a) Inadequate braking effort on one or more wheels.</li> <li>Or, in the case of testing on the road, the vehicle deviates excessively from a straight line and/or excessive vibration is produced at the service brake pedal/lever.</li> <li>No braking effort on one or more wheels.</li> </ul>	X X	X
			(b) Braking effort from any wheel is less than 70 % of the maximum effort recorded from the other wheel on the same axle. Or, in the case of testing on the road, the vehicle deviates excessively from a straight line. Braking effort from any wheel is less than 50 % of the	Х	X
		maximum effort recorded from the other wheel on the same axle in the case of steered axles.			
		(c) No gradual variation in brake effort (grabbing).	X		
			(d) Abnormal lag in brake operation of any wheel.	Х	
			(e) Excessive fluctuation of brake force during each complete wheel revolution.	Х	
1.2.2.	Efficiency(E)	Test with a brake tester at the presented weight or, if one cannot be used for technical	Does not give at least the minimum figure as follows ( <sup>2</sup> ):		
		reasons, by a road test using a deceleration recording instrument ( <sup>1</sup> ).	Categories $M_1$ , $M_2$ and $M_3$ : 50 % ( <sup>3</sup> )	Х	
			Category N1: 45 %		
			Categories $N_2$ and $N_3{:}$ 43 % (4)		
			Categories $O_3$ and $O_4$ : 40 % ( <sup>5</sup> )		
			Category T: 40%		
			Less than 50 % of the above values reached		Х

6

6

(viii) in the table, item 1.3.1 is replaced by the following:

1.3.1. Performance (E)	If the secondary braking system is separate from the service braking system, use the method specified in 1.2.1.	(a) Inadequate braking effort on one or more wheels.	Х	
	It must be ensured that, where possible, the mechanical brakes are inspected without interference/blending of regenerative braking or other continuous braking. (b) Braking effort from any wheel is maximum effort recorded from a same axle specified. Or, in the case the vehicle deviates excessively from the braking effort from any wheel is maximum effort recorded from the same axis and the vehicle deviates excessively from the same axis and the same axis and the vehicle deviates excessively from the same axis and the sam	No braking effort on one or more wheels.		Х
		(b) Braking effort from any wheel is less than 70 % of the maximum effort recorded from another wheel on the same axle specified. Or, in the case of testing on the road, the vehicle deviates excessively from a straight line.	Х	
		Braking effort from any wheel is less than 50 % of the maximum effort recorded from the other wheel on the same axle in the case of steered axles.		X
		(c) No gradual variation in brake effort (grabbing).	Х	

### ';

6

';

(ix) in the table, item 1.4.1 is replaced by the following:

1.4.1. Performance (E)	Apply the brake during a test on a brake tester or by road test.	Brake inoperative on one side or, in the case of testing on the road, the vehicle deviates excessively from a straight line.	Х	
		Less than 50 % of the braking effort values as referred to in point 1.4.2 reached in relation to the vehicle mass during testing.		Х

(x) in the table, item 1.5 is replaced by the following:

EN

1.5.	Endurance braking system performance	Visual inspection and, where possible, test whether the system functions, i.e. by road test.	(a) Malfunction indicator indicates a fault.	Х	
			(b) System not functioning.	Х	

6

(xi) in the table, item 1.6 is deleted;

(xii) in the table, item 2.6 is deleted;

6

(xiii) in the table, item 4.1.1 is replaced by the following:

4.1.1.	Condition and operation	Visual inspection and by operation.	(a) Defective or missing light source.			
			Multiple light sources (in the case of LED, up to 1/3 not functioning).	Х		
			Seriously affected visibility.		Х	
			(b) Slightly defective projection system (reflector and lens).	Х		
			Heavily defective or missing projection system (reflector and lens).		Х	
			(c) Lamp not securely attached.		Х	
			(d) System indicates failure for example via the electronic vehicle interface.		Х	

';

(xiv) in the table, item 4.1.5 is replaced by the following:

4.1.5. Manual levelling devices (where mandatory)	Visual inspection and by operation, if possible, or using the electronic vehicle		Х	
	interface	(b) Device cannot be operated from driver's seat.	Х	

6

6

6

(xv) in the table, item 4.2.1 is replaced by the following:

4.2.1. Condition and operation	Visual inspection and by operation.	<ul><li>(a) Defective or missing light source</li><li>Multiple light sources (in the case of LED, up to 1/3 not functioning); one of several lateral light sources defective.</li></ul>	Х		
		Seriously affected visibility (in the case of LED, less than 2/3 functioning).		Х	
		(b) Defective lens.		Х	
		(c) Lamp not securely attached.	Х		
		Very serious risk of falling off.		Х	

;

(xvi) in the table, item 4.3.1 is replaced by the following:

4.3.1.	Condition and operation	Visual inspection and by operation	(a) Defective or missing light source.			
			Multiple light sources; in the case of LED up to $1/3$ not functioning).	Х		
			Single light sources; in the case of LED less than 2/3 functioning.		Х	
			All light sources not functioning.			Х

(b) Slightly defective lens (no influence on emitted light).	Х		
Heavily defective lens (emitted light affected).		Х	
(c) Lamp not securely attached.	Х		
Very serious risk of falling off,		Х	

4

';

(xvii) in the table, item 4.4.1 is replaced by the following:

Item	Method	Reasons for failure Assessment of defi			iencies
			Minor	Major	Dangerou
4.4.1. Condition and operation	Visual inspection and by operation.	(a) Defective or missing light source			
		Multiple light sources ( in the case of LED up to $1/3$ not functioning).	Х		
		Single light sources; in the case of LED less than 2/3 functioning.		Х	
		No light source functioning.			x
		(b) Slightly defective lens (no influence on emitted light).	Х		
		Heavily defective lens (emitted light affected).		X	
		(c) Lamp not securely attached.	Х		
		Very serious risk of falling off.		X	

(xviii) in the table, item 4.5.1 is replaced by the following:

4.5.1.	Condition and operation	Visual inspection and by operation	(a) Defective or missing light source			
			Multiple light source; in thecase of LED up to 1/3 not functioning.	Х		
			Single light sources; in the case of LED less than 2/3 functioning.		Х	
			(b) Slightly defective lens (no influence on emitted light).	Х		
			Heavily defective lens (emitted light affected).		Х	
			(c) Lamp not securely attached.	Х		
			Very serious risk of falling off or dazzling oncoming traffic.		Х	

';

6

';

6

(xix) in the table, item 4.6.1 is replaced by the following:

1.1.1.1.1.4			
gle light sources; in the case of LED less than 2/3 ctioning.		Х	
Defective lens.	Х		
Lamp not securely attached.	Х		
l o	Lamp not securely attached. Very serious risk of falling off.	1 5	

(xx) in the table, item 4.7.1 is replaced by the following:

.7.1.	Condition and operation	Visual inspection and by operation	(a) Lamp throwing direct or white light to the rear.	Х		
			(b) Defective or missing light source (multiple light source).	Х		
			Defective or missing light source (single light source).		Х	
			(c) Lamp not securely attached.	Х		
			Very serious risk of falling off.		Х	

';

6

6

(xxi) in the table, in item 4.11, the title in the first column is replaced by the following:

'Electrical wiring (except high-voltage wiring)';

(xxii) in the table, in item 4.13, the title in the first column is replaced by the following:

'Battery (or batteries, except high-voltage batteries)';

(xxiii) in the table, the following item 4.14 is inserted:

4.14 High-voltage systems							
4.14.1 Electrical safety	Visual inspection complemented by using the vehicle interface	(a) Indicator or vehicle interface shows system malfunction		Х			
		(b) Software version or -integrity incorrect		Х			
4.14.2 Traction battery cover	Visual inspection.	(a) Slightly deteriorated Heavily deteriorated	Х				

				Х	
		(b) Defective attachment		Х	
		Very serious risk of falling off			Х
		(c) Obstructed ventilation port(s)	Х		
4.14.3 Traction battery	Visual inspection, complemented by using the vehicle interface (where made possible by the technical characteristics of the	<ul><li>(a) Marks of leakage</li><li>Leaking (presence of droplets)</li></ul>		Х	Х
	vehicle, and where the necessary data are available).	(b) Incorrect software or hardware, or readiness-code not active		Х	
4.14.4 High voltage electrical wiring	<u>.</u>				
4.14.4.1 High voltage wiring harness and	Visual inspection and by operation with the	(a) Slightly deteriorated	Х		
connector	vehicle over a pit or on a hoist, including inside the engine compartment and the boot	Heavily deteriorated		Х	
	(where applicable)	Risk of short-circuit fault			Х
		(b) Wiring insecure or not adequately secured	Х		
		Fixings loose, touching sharp edges, connectors likely to be disconnected		Х	
		Wiring likely to touch hot parts, rotating parts or the ground, connectors disconnected			Х
		(c) Imminent risk of fire, formation of sparks			Х
4.14.4.2 Ground braid, including their	Visual inspection and by operation.	Slightly deteriorated	Х		
attachment		Heavily deteriorated		Х	
4.14.4.3 Ground continuity $(X)^2$	Measurement using an ohmmeter	Test not feasible	Х		
		Too high resistance (over 100 Ohms)		Х	
4.14.4.4 Charging inlet cover	Visual inspection and by operation.	Deteriorated	Х		
		Missing		Х	
4.14.4.5 Charging inlet	Visual inspection and by operation.	(a) Deteriorated	Х		
		Trace of beginning of melting or electric arcs		Х	
		(b) Foreign material or moisture		Х	
4.14.4.6 Charging cable	Visual inspection and by operation.	(a) Deteriorated	Х		

		(b) Charging cable not provided	Х		
4.14.5. High voltage electrical and electronica	al equipment (X) <sup>2</sup>				
4.14.5.1. High voltage electrical and electronical equipment	Visual inspection and by using the electronic vehicle interface.	(a) Slightly deteriorated Heavily deteriorated	Х	X	
		(b) Attachment defective		Х	
		(c) Leaking		Х	
4.14.5.2. Traction motor	Visual inspection	(a) Shield is deformed, not in-place or damaged, or corroded		Х	
	Check of operational readiness of the	(b) Warning marking missing or illegible		Х	
	systems by an applicable interface (OBD or OBM)	(c) Connection of wiring harness insecure or corroded		Х	
	Measurement of equipotential bonding, where made possible by the technical characteristics of the vehicle	<ul> <li>(d) Electrical insulation damaged or deteriorated likely to cause injury when contacted.</li> </ul>		Х	х
		(e) Fault readiness of the traction motor		Х	
		(f) Wrong version of type-approved hardware and software not in accordance with the requirements as defined in the ECE R100		Х	
4.14.5.3 Electronic converters, motor, and	Visual inspection	(a) Not in accordance with requirements <sup>1</sup>		Х	
inverter	Check of operational readiness of the	(b) Inadequately secured		Х	
	systems by an applicable interface (OBD or OBM)	(c) Damaged or corroded components	Х	V	
		Likely to cause injuries or to fall off (d) Shields not in place or damaged		X X	
	Measurement of equipotential bonding, where made possible by the technical characteristics of the vehicle	(c) Damaged or deteriorated electrical insulation		X	
		(f) Fault readiness of the converter and inverter systems		Х	
		(g) Wrong version of type-approved hardware and software		Х	

4.14.6. Insulation resistance $(X)^2$					
4.14.6.1. Insulation resistance of the vehicle charging inlet and resistance of the protective earthing	Read insulation resistance by the electronic vehicle interface, where made possible by the technical characteristics of the vehicle	(c) Insulation resistance is not in accordance with requirements or predefined values from the vehicle manufacturer		Х	
	and where the necessary data is made available	(d) Resistance of the protective earthing is not in accordance with requirements		Х	
4.14.6.2. Insulation resistance between the	Visual inspection	(c) Insulation monitoring system shows malfunction		Х	
high-voltage system and chassis	Read insulation resistance by the electronic vehicle interface, where made possible by the technical characteristics of the vehicle and where the necessary data is made available	(d) Insulation resistance value not in accordance with requirements		Х	
4.14.7. Anti-starting system					
4.14.7.1. Anti-starting system	Visual inspection and by operation when possible.	(a) Indicator malfunction	Х		
	Functional check by verifying that the vehicle cannot move by itself with the charging cable plugged, and the driver's weight lifted out of the seat	(b) Inoperative, i.e., vehicle can move with connected charging cable or with no driver present		Х	

4

(xxiv) in the table, item 5.1.3 is replaced by the following:

5.1.3.	Wheel bearings	Visual inspection using. wheel play detectors if available. Rock the wheelor		Х	
	(+ E)	apply a lateral force to each wheel and note the amount of upwardmovement of the wheel relative to the stub axle.	Directional stability impaired; danger of		Х
		the wheel relative to the stud axie.	(b) Wheel bearing too tight, jammed.	Х	
			Danger of overheating; danger of demolishment.		Х
			(a) Audible signs of bearing wear or damage.	Х	

';

(xxv) in the table, items 7.1.3, 7.1.4, 7.1.5, and 7.1.6 are deleted;

(xxvi) in the table, item 7.8 is replaced by the following:

7.8. Speedome	Speedometer	Visual inspection or by operation during road test or by using the electronic vehicle interface, or any combination of these.	(a) Not fitted in accordance with the requirements <sup>1</sup> .	Х		
			Missing (if required).		Х	
			(b) Operation impaired.	Х		
			Not operational at all.		Х	
		(c) Not capable of being sufficiently illuminated.	Х			
			Not capable of being illuminated at all.		Х	

';

6

6

(xxvii) in the table, items 7.9 and 7.10 are deleted;

(xxviii) in the table, item 7.11 is replaced by the following:

7.11.	Odometer, if available	Visual inspection, and/or using electronic interface (OBD or OBM)	<ul> <li>(a) Obviously manipulated (fraud) to reduce or misrepresent the vehicle's distance record.</li> </ul>	Х	
			(b) Obviously inoperative.	Х	

';

(xxix) in the table, items 7.12 and 7.13 are deleted;

(xxx) in the table, items 8.1 and 8.2 are replaced by the following:

8.1. Noise

8.1.1.		For L-category vehicles powered by internal combustion engines, visual inspection and measurement of noise emitted by stationary vehicle using a sound level meter. For other vehicles, subjective evaluation (unless the inspector considers that the noise level may be borderline, in which case a measurement of noise emitted by stationary vehicle using a sound level meter may be	<ul> <li>(a) Noise levels in excess of those permitted in the requirements<sup>1</sup>.</li> </ul>	х	
			<ul> <li>(b) Any part of the noise suppression system loose, damaged, incorrectly fitted, missing or obviously modified in a way that would adversely affect the noise levels.</li> <li>Very serious risk of falling off.</li> </ul>	Х	Х
		conducted).			
		Measurement using remote sensing equipment	(c) Remote sensing measurement showing significant non- compliance.	х	
3.2.	Exhaust emissions		·		
8.2.1.	possible by the technical characteristics of the	possible by the technical characteristics of the vehicle and where the necessary data is made available, with the use of electronic interface	(a) Emission control equipment fitted by the manufacturer absent, modified or obviously defective.	Х	
			(b) Leaks which would affect emission measurements.	Х	
			(c) Warning device malfunctioning, warning indicator / tell- tale inoperative.	Х	
			(d) MIL activated, warning device shows system malfunction.	Х	
			(e) System indicates failure via the electronic vehicle interface.	Х	
			(f) Exhaust emission control unit modified affecting safety and/or the environment.	Х	
			(g) Any other emission relevant control unit modified affecting safety and/or the environment.	Х	
		(h) Presence of electronic devices not authorised by the vehicle manufacturer nor approved during homologation changing signals to or from the engine or pollution control unit(s).	x		

(i) Insufficient reagent, if applicable. X
(j) OBD or OBM read-out indicating significant X malfunction.

Item	Method Reasons for failure		Assessment of deficiencies		
			Minor	Major	Dangerous
8.2.2 Exhaust emission measurement – positive	Test procedures:				
ignition engines	For vehicles that had a particle number (PN) limit at type-approval; Euro VI, Euro 6c and newer:				
	Particle number (PN) measurement in accordance with 8.2.2.1.				
	For all vehicles:				
	Gaseous emissions test in accordance with 8.2.2.2.				
	For vehicles as of emission classes Euro VI, Euro 6d-TEMP and newer:				
	NO <sub>X</sub> measurement in accordance with 8.2.2.3.				
8.2.2.1 Particle number measurement (E)	Vehicle preconditioning:	Measurement result exceeds [to be specified in accordance with the delegated acts referred to in Article 21] (1/cm <sup>3</sup> ).		x	
	<ul> <li>[to be specified in accordance with the delegated acts referred to in Article 21].</li> </ul>				
	Measuring instrument preparation:				
	— The device to measure PN is powered on for at least the warm-up time indicated by the manufacturer;				
	— Self-checks of the instrument [to be specified in accordance with the delegated acts referred to in Article 21], to monitor the proper operation of the instrument during operation and trigger a warning or message in case of malfunction;				
	Before each test, the good condition of the sampling system shall be verified, including checking the sampling hose and probe for damage.				
	Test procedure:				

<ul> <li>The software of the particle counter</li> </ul>
automatically guides the instrument operator
through the test procedure;
— The probe is inserted at least 0,20 m into the
outlet of the exhaust system. In justified

outlet of the exhaust system. In justified exemptions where sampling at this depth is not possible, the probe is inserted at least 0,05 m. The sampling probe shall not touch the walls of the tailpipe;

— If the exhaust system has more than one outlet, the test shall be done to all of them. In this case, the highest measured PN concentration measured at different exhaust system outlets shall be considered as the vehicle's PN concentration;

— The vehicle operates [as specified in accordance with the delegated acts referred to in Article 21]. In case the engine of a vehicle is not switched on at static conditions then the start/stop system shall be deactivated by the test operator. For hybrid and plug-in hybrid vehicles, the thermal engine shall be switched on;

— After the probe has been inserted into the tailpipe, the following steps shall be followed:

- A stabilization period of at least 15 seconds with the engine running at idle speed.
- After the stabilisation period, the PN concentration emissions are measured. The duration of the test shall be at least [XX] seconds (total measurement duration) [to be specified in accordance with the delegated acts referred to in Article 21].

After the completion of the test procedure, the instrument reports (and stores) the PN concentration of the vehicle and a "PASS" or "FAIL" message:

	<ul> <li>If the test result is less than or equal to the limit, the instrument reports a "PASS" message.</li> <li>If the test result is greater than the limit, the instrument reports a "FAIL" message.</li> </ul>			
8.2.2.2. Gaseous emissions (E)	Measurement using an exhaust gas analyser in accordance with the requirements <sup>1</sup> .	(a) Either gaseous emissions exceed the specific levels given by the manufacturer;	Х	
	Measurements not applicable for two-stroke engines. Alternatively, measurement using remote sensing equipment and confirmed by standard test methods.	<ul> <li>(i) for vehicles not controlled by an advanced emission control system,</li> <li>4,5 %, or</li> <li>3,5 % according to the date of first registration or use specified in requirements<sup>1</sup>.</li> <li>(ii) for vehicles controlled by an advanced emission control system,</li> <li>at engine idle: 0,5 %</li> <li>at high idle: 0,3 % or</li> <li>at engine idle: 0,3 % (<sup>7</sup>)</li> <li>at high idle: 0,2 % (<sup>8</sup>)</li> <li>at high idle: 0,1 % according to the date of first registration or use specified in requirements<sup>1</sup>.</li> </ul>	X	
8.2.2.3. NO <sub>X</sub> measurement (E)	Vehicle preconditioning: [to be specified in accordance with the delegated acts referred to in Article 21]; - []	<ul> <li>in accordance with the manufacturer's specification;</li> <li>(a) Measurement result exceeds [NO<sub>X</sub> limit to be specified in accordance with the delegated acts referred to in Article 21].</li> </ul>	X	
	Measuring instrument preparation: — [to be specified in accordance with the delegated acts referred to in Article 21) or			

combined with PN measurement in accordance with 8.2.2.1]; — Self-checks of the instrument [to be specified in accordance with the delegated acts referred to in Article 21]; Before each test, the good condition of the sampling system shall be verified, including checking the sampling hose and probe for damage. Test procedure: — [to be specified in accordance with the delegated acts referred to in Article 21 or combined with PN measurement in accordance	malfunction.	Х	
with 8.2.2.1]; Alternatively, measurement using remote sensing equipment and confirmed by standard test methods in accordance with item 8.2.2. in this table or with item 8.2.2 in point 3 of Annex I to Directive 2014/45/EU.			

Item	Method	Reasons for failure	Assessment of det		deficiencies
			Minor	Major	Dangerous
8.2.3 Exhaust emission measurement	-Test procedures:				
compression ignition engines	For vehicles as of emission classes Euro 5b and Euro VI and newer:	1			
	PN measurement in accordance with 8.2.3.1				
	For vehicles up to emission classes Euro 5a and Euro V:				
	Opacity measurement in accordance with 8.2.3.2.				
	For vehicles equipped with particle filters, Member States may apply PN measurement in accordance with 8.2.3.1 instead of opacity measurement.				
	For vehicles as of emission classes Euro 6d-TEMP and Euro VI and newer:	>			
	NO <sub>X</sub> measurement in accordance with 8.2.3.3.				
8.2.3.1 Particle number measurement (E)	Vehicle preconditioning:	Measurement result exceeds 250 000 (1/cm <sup>3</sup> )		Х	
	At the beginning of the test the vehicle's engine should be:				
	— Hot, i.e., engine coolant temperature above 60 °C but preferably above 70 °C	and Euro V, equipped with particle filters			
	— Conditioned, by operating for a period of time at low idling and/or performing stationary accelerations up to maximum 2 000 rpm engine speed or by driving. The recommended total conditioning time is at least 300 seconds.	000 000 (1/cm )			
	During the test, the vehicle shall not be performing an active particulate filter regeneration.				
	A fast pass test is possible with engine coolant temperature below 60 °C. However, if the vehicle fails to pass the test, the test shall be repeated, and the vehicle should fulfil the requirements set for the engine coolant temperature and the conditioning.				
	Measuring instrument preparation:				
	— The instrument is powered on for at least the warm-up time indicated by the manufacturer;	2			

Self-checks of the instrument as defined in Section 5 of Commission Recommendation (EU) 2023/688, as adopted on 20 March 2023, to monitor the proper operation of the instrument during operation and trigger a warning or message in case of malfunction;

Before each test, the good condition of the sampling system shall be verified, including checking the sampling hose and probe for damage.

Test procedure:

 The software of the particle counter automatically guides the instrument operator through the test procedure;

— The probe is inserted at least 0,20 m into the outlet of the exhaust system. In justified exemptions where sampling at this depth is not possible, the probe is inserted at least 0,05 m. The sampling probe shall not touch the walls of the tailpipe;

— If the exhaust system has more than one outlet, the test shall be done to all of them. In this case, the highest measured PN concentration measured at different exhaust system outlets shall be considered as the vehicle's PN concentration;

— The vehicle operates at low idling. In case the engine of a vehicle is not switched on at static conditions then the start/stop system shall be deactivated by the test operator. For hybrid and plug-in hybrid vehicles, the thermal engine shall be switched on;

— After the probe has been inserted into the tailpipe, the following steps shall be followed:

1. A stabilization period of at least 15 seconds with the engine running at idle speed. Optionally, before the stabilization period 2-3 accelerations up to maximum 2 000 rpm engine speed are performed,

2. After the stabilisation period, the PN concentration emissions are measured. The duration of the test shall be at least 15 seconds (total measurement duration). The test result shall be the average PN concentration of the measurement duration. If the measured PN concentration is more than two times the limit, the measurement may stop immediately before waiting for 15 seconds to elapse. The test result shall be reported.

	After the completion of the test procedure, the instrument reports (and stores) the average PN concentration of the vehicle and a "PASS" or "FAIL" message: — If the test result is less than or equal to the limit, the instrument reports a "PASS" message. — If the test result is greater than the limit, the instrument reports a "FAIL" message.			
8.2.3.2. Opacity Vehicles registered or put into service before 1 January 1980 are exempted from this requirement	Exhaust gas opacity to be measured during free acceleration (no load from idle up to cut-off speed) with gear lever in neutral and clutch engaged and, if specified in accordance with the type-approval regulations, reading of OBD in accordance with the manufacturer's recommendations and other requirements.	in requirements <sup>1</sup> .	Х	
	<ul><li>Vehicle preconditioning:</li><li>1. Vehicles may be tested without preconditioning, although for safety reasons checks should be made that the engine is warm and in a satisfactory mechanical condition.</li></ul>			

Item	Method	Reasons for failure	Assessment of deficiencies			
			Minor	Major	Dangerous	
	<ol> <li>Precondition requirements:         <ol> <li>Engine shall be fully warm, for instance the engine oil temperature measured by a probe in the oil level dipstick tube to be at least 80 °C, or normal operating temperature if lower, or the engine block temperature measured by the level of infrared radiation to be at least an equivalent temperature. If, owing to the vehicle configuration, this measurement is impractical, the establishment of the engine's normal operating temperature may be made by other means, for example by the operation of the engine cooling fan.</li> <li>Exhaust system shall be purged by at least three free acceleration cycles or by an equivalent method.</li> </ol> </li> </ol>	$m^{-1}$ , — for turbo-charged engines: 3,0 $m^{-1}$ , or				
	<ol> <li>Engine and any turbocharger fitted, to be at idle before the start of each free acceleration cycle. For heavy-duty diesels, this means waiting for at least 10 seconds after the release of the throttle.</li> <li>To initiate each free acceleration cycle, the throttle pedal must be fully depressed quickly and continuously (in less than one second) but not violently, so as to obtain maximum delivery from the injection pump.</li> </ol>					

Item	Method	Reasons for failure	Asse	ssment of defi	iciencies
			Minor	Major	Dangero
	<ol> <li>During each free acceleration cycle, the engine shall reach cut-off speed or, the speed specified by the manufacturer or, if this data is not available, then two thirds of the cut-off speed, before the throttle is released. This could be checked, for instance, by monitoring engine speed or by allowing a sufficient time to elapse between initial throttle depression and release, which in the case of vehicles of categories M<sub>2</sub>, M<sub>3</sub>, N<sub>2</sub> and N<sub>3</sub>, should be at least two seconds.</li> <li>Vehicles shall only be failed if the arithmetic means of at least the last three free acceleration cycles are in excess of the limit value. This may be calculated by ignoring any measurement that departs significantly from the measured mean, or the result of any other statistical calculation that takes account of the scattering of the measurements. Member States may limit the number of test cycles.</li> <li>To avoid unnecessary testing, Member States may fail vehicles which have measured values significantly in excess of the limit values after fewer than three free acceleration cycles or after the purging cycles. Equally to avoid unnecessary testing, Member States may pass vehicles which have measured values significantly below the limits after fewer than three free acceleration cycles or after the purging cycles or after the purging cycles. Alternatively, measurement usingremote sensing equipment and confirmed by standard test methods in accordance with item 8.2.3 of this table or with item 8.2.3 in point 3 of Annex I to Directive 2014/45/EU.</li> </ol>				

Item	Method	Reasons for failure	Assessment of deficiencies		
			Minor	Major	Dangerous
8.2.3.3. NO <sub>X</sub> measurement (E)	<ul> <li>Vehicle preconditioning:</li> <li>Prior to testing, the vehicle's exhaust aftertreatment system shall be warmed up, to the conditions that allow effective abatement of NO<sub>X</sub> emissions by the selective catalytic reduction (SCR) unit of the vehicle by at least a 5-minute drive or an equivalent method. Once the condition is reached, the vehicle shall not be turned off and the measurement shall be performed within 3 minutes for M<sub>1</sub> and N<sub>1</sub> vehicles and within 3.5 minutes for M<sub>2</sub>, M<sub>3</sub>, N<sub>2</sub> and N<sub>3</sub> vehicles. Where possible, the vehicle's readiness to be tested shall be ascertained by checking the indicator lamp on the dashboard or via the vehicle interface (OBD or OBM read-out).</li> <li>During the test, the vehicle shall not be performing an active particulate filter regeneration.</li> <li>Measuring instrument preparation:</li> <li>— The device to measure NO<sub>X</sub> emissions is powered on for at least the warm-up time indicated by the manufacturer;</li> <li>— Self-checks of the instrument [to be specified in accordance with the delegated acts referred to in Article 21] to monitor the proper operation of the instrument during operation and trigger a warning or message in case of malfunction;</li> <li>Before each test, the good condition of the sampling hose and probe for damage.</li> </ul>			X	

Test procedure:
— The software of the NO <sub>X</sub> analyser automatically guides the instrument operator through the test procedure;
— The probe is inserted at least 0,20 m into the outlet of the exhaust system. In justified exemptions where sampling at this depth is not possible, the probe is inserted at least 0,05 m. The sampling probe shall not touch the walls of the tailpipe;
— If the exhaust system has more than one outlet, the test shall be done to all of them. In this case, the highest measured $NO_X$ concentration measured at different exhaust system outlets shall be considered as the vehicle's $NO_X$ concentration;
— The vehicle operates at low idling;
— After the probe has been inserted into the tailpipe, the following steps shall be followed:
<ol> <li>A stabilization period of at least 15 seconds with the engine running at idle speed.</li> <li>After the stabilisation period, the NO<sub>X</sub> concentration emissions are measured. The duration of the test shall be at least 15 seconds (total measurement duration). The test result shall be the average NO<sub>X</sub> concentration of the measurement duration.</li> </ol>
After the completion of the test procedure, the instrument reports (and stores) the average NO <sub>X</sub> concentration of the vehicle and a "PASS" or "FAIL" message:
— If the test result is less than or equal to the limit, the instrument reports a "PASS" message.
— If the test result is greater than the limit, the instrument reports a "FAIL" message.
Alternatively, measurement usingremote sensing equipment and confirmed by standard test methods in accordance with item 8.2.3 in this table or item 8.2.3 in point 3 of Annex I to Directive 2014/45/EU.

(xxxi) in the table, item 8.4.1, is replaced by the following:

8.4.1. Fluid leaks	Visual inspection	Any excessive fluid leak, other than water, likely to harm the environment or to pose a safety risk to other road users.	Х	
		Steady formation of drops that constitutes a very serious risk.		Х

(xxxii) in the table, the following item 10 is added:

6

10. ELECTRONIC SAFETY SY	STEMS				
10.1. Cornering light Description: during cornering, an	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
extra headlamp is activated. Operates up to 40 km/h, for example	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
in accordance with UNECE-R 48 or UNECE-R 119.	use of electronic interface	(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		х	
		(h) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.2 Adaptive cruise control Description: The system maintains	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		х	
the vehicle's speed, depending on the preferred speed and distance to the	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged, or sensors obviously misaligned		х	
vehicle in front.	use of electronic interface	(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	

				-	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			х
10.3 Adaptive deflectors Description: Depending on the	made possible by the technical - characteristics of the vehicle and where the	(a) System or any component missing		Х	
vehicle's speed, the air deflectors are adjusted in order to improve driving		(b) System or components damaged		Х	
stability.		(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	x		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	X		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х

10.4 Airbag Description: In case of an accident, inflatable airbags reduce the risk of	made possible by the technical	(a) System or components (for example seat occupancy detection) obviously missing.		Х	
injury by their absorbing effect, for example in accordance with	necessary data is made available, with the use of electronic interface	(b) System or components damaged		Х	
UNECE-R 12; UNECE-R 14; or UNECE-R 16.		(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board			Х
		(g) System or components obviously not operating (for example not suitable with the vehicle)		Х	
		(h) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board			Х
10.5 Active Headrest Description: the system reduces the	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
danger of a whiplash injury in the event of a rear end collision by	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
changing the position of the headrest towards the head.	use of electronic interface	(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	

		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board			Х
		(g) System or components not operating, where applicable, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board			Х
10.6 Active hood Description: by automatically lifting	made possible by the technical characteristics of the vehicle and where the	(a) System or any component missing		Х	
the bonnet, the system ensures a larger collapsible zone in the event		(b) System or components damaged		Х	
of an accident involving a pedestrian.		(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			х
		(g) System or components not operating (for example outdated), where applicable, or implausible operation		Х	

		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.7 Automatic hold function Description: the system	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
independently holds the vehicle after stopping using the service brake	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
and/or parking brake and automatically releases them when	use of electronic interface	(c) Software version or -integrity incorrect		Х	
starting.		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.8 Automatic headlamp levelling Description: depending on the load	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
and (optional) pitch angle, the system regulates the headlamp's	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
vertical aim, for example in accordance with UNECE-R 121.	use of electronic interface	(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	

		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.9 Automatic emergency braking system	made possible by the technical characteristics of the vehicle and where the	(a) System or any component missing		Х	
Description: the system independently starts braking in order		(b) System or components damaged, or sensors obviously misaligned		Х	
to avoid a collision with an obstacle or another road user, or to reduce the	use of electronic interface	(c) Software version or -integrity incorrect		Х	
consequences of an inevitable impact.		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operative (for example audio components)		Х	

			1		
		(h) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.10 Anti-lock braking system Description: the system	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
automatically prevents wheel- locking during braking by selective	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components (for example wheel speed sensor) damaged		Х	
reduction of the wheel brake force, for example in accordance with	use of electronic interface	(c) Software version or -integrity incorrect		Х	
UNECE-R 13 and Regulation (EU) 2019/2144.		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			х
10.11 Automatic light Description: depending on the	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
ambient brightness, the system automatically switches on and off	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
the driving light.	use of electronic interface	(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	

		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.12 Electro-mechanic power steering	made possible by the technical - characteristics of the vehicle and where the	(a) System or any component missing		Х	
Description: the supporting power for steering is generated by an		(b) System or components damaged		Х	
electric motor.		(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating (for example Power assistance not working), or implausible operation (for example inconsistency between the angle of the steering wheel and the angle of the wheels.)		Х	
		Steering affected			Х

					1
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.13 Electronic four-wheel steering Description: two axles are steered,	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
with a steering angle greater than 3° on all steered wheels, for example in	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
accordance with UNECE-R 79 and Regulation (EU) 2019/2144.	use of electronic interface	(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	x		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.14 Electronic damping Description: depending on the	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
Description: depending on the driving situation, the rebound and compression stage of the shock	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
absorbers is adjusted by the system.	use of electronic interface	(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	

		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	x		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	X		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.15 Electronic brake system Description: a brake pedal sensor	made possible by the technical characteristics of the vehicle and where the	(a) System or any component missing		Х	
and/or pressure sensor records the braking request and calculates the		(b) System or components damaged		Х	
optimal brake force for each wheel, so that there is optimal activation of	use of electronic interface, or by road test.	(c) Software version or -integrity incorrect		Х	
all wheel brakes.		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	X		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	

			1	-	
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.16 Electronic stability program Description: the system stabilizes the vehicle or the complete vehicle	Visual inspection complemented, where made possible by the technical characteristics of the vehicle and where the	(a) System or any component (for example wheel speed sensors) missing		Х	
train in critical, dynamic driving situations, for example in	necessary data is made available, with the use of electronic interface	(b) System or components (for example wheel speed sensors) damaged		х	
accordance with Regulation (EU) 2019/2144 and UNECE-R 140.		(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		х	
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.17 High beam assist Description: the system	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
Description: the system automatically activates and deactivates the high beam according to the driving situation and lighting conditions.	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
	use of electronic interface	(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	

	l de la constante de			1	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.18 Speed limiter Description: While driving, the system prevents exceeding a defined	Visual inspection complemented, where made possible by the technical characteristics of the vehicle and where the	(a) System or any component missing (for example seals, plaques), or not fitted in accordance with the requirements.		Х	
maximum speed. Relevant, if mandatory, for example in	necessary data is made available, with the	(b) System or components damaged		Х	
accordance with UNECE-R 89 and Regulation (EU) 2019/2144.		(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			х
		(g) System or components not operating, or implausible operation (for example tampered or manipulated, or size of tyres not compatible with calibration parameters, or incorrect set speed, if checked).		Х	

r				1	
		(h) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.19 Belt tensioner and belt force limiter	Visual inspection complemented, where made possible by the technical	(a) System or any component missing, or not suitable with the vehicle		Х	
Description: In the event of an accident, the seat belt is tensioned to	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
place the passengers in a setpoint position and/or limits the belt force,	use of electronic interface	(c) Software version or -integrity incorrect		Х	
electrically controlled and, thus, limits the forces acting on the persons for example in accordance		(d) Wiring damaged		Х	
with UNECE-R 16 or UNECE-R 94.		(e) Warning device shows system malfunction.		х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board			Х
		(g) System or components not operating, where applicable, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board			Х
10.20 Taillight switching Description: Depending on	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
operating status and/or failure of the illuminants, lighting functions are	characteristics of the vehicle and where the necessary data is made available, with the use of electronic interface	(b) System or components damaged		Х	
taken over by other luminaires.		(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	

		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	x		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.21 Bending light Description: during cornering and	made possible by the technical characteristics of the vehicle and where the	(a) System or any component missing		Х	
depending on the steering angle and speed, the light beam is swivelled		(b) System or components damaged		Х	
and/or an additional headlight is activated, for example in accordance	use of electronic interface	(c) Software version or -integrity incorrect		Х	
with UNECE-R 48; UNECE-R 98; UNECE-R 112; or UNECE-R 123.		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	x		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	

				-	
		(h) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.22 Steering assist Description: depending on the	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
driving situation, the steering angle is automatically changed, without	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
intervention by the driver. Relevant if the steering intervention occurs at	use of electronic interface	(c) Software version or -integrity incorrect		Х	
a speed of more than 15 km/h, for example in accordance with UNECE-R 79.		(d) Wiring damaged		Х	
UNECE-K /9.		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operative (for example audio components)		Х	
		(h) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			х
10.23 Height levelling Description: the system changes the	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
clearance between vehicle chassis and the road.	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
	use of electronic interface	(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	

		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	x		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.24 Emergency braking signal Description: during strong	made possible by the technical characteristics of the vehicle and where the	(a) System or any component missing		Х	
deceleration, hazard warning lights and/or additional luminous surfaces		(b) System or components damaged		Х	
are activated and/or the following traffic is warned by flashing brake	use of electronic interface	(c) Software version or -integrity incorrect		Х	
lights, for example in accordance with UNECE-R 48 or UNECE-R 13.		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	

			1		
		(f) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.25 Pre-crash system Description: in a critical driving	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
situation, the vehicle is prepared for the crash so that the risk of injury to	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
the passengers and/or other road users is reduced.	use of electronic interface	(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			х
		(g) System or components not operating, or implausible operation (for example power windows)		Х	
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			х
10.26 Tyre pressure warning Description: the system detects loss	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
of tyre pressure through integrated sensors and/or by implausible values	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
for wheel speed, for example in accordance with Regulation (EU)	use of electronic interface	(c) Software version or -integrity incorrect		Х	
2019/2144 and UNECE-R 141.		(d) Wiring damaged		Х	

		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	x		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.27 Traction control Description: the system prevents the	made possible by the technical characteristics of the vehicle and where the	(a) System or any component missing		Х	
drive wheels spinning during acceleration by applying brake		(b) System or components damaged		Х	
force.		(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	

			1		
		(h) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.28 Superimposed steering Description: depending on the	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
driving situation, the system varies the transmission ratio of the steering.	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
	use of electronic interface	(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating (for example Power assistance not working), or implausible operation (for example inconsistency between the angle of the steering wheel and the angle of the wheels.)		Х	
		Steering affected			Х
		(h) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.29 Roll over protection (active) Description: in the event of an	Visual inspection complemented, where made possible by the technical characteristics of the vehicle and where the	(a) System or any component missing		Х	
imminent rollover, support elements		(b) System or components damaged		Х	

			I	-	
are extended to secure the survival space, for example in accordance	use of electronic interface	(c) Software version or -integrity incorrect		Х	
with Regulation (EU) 2019/2144 and UNECE-R 21.		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.30 Hydrogen installation Description: the hydrogen is stored	Visual inspection complemented, where made possible by the technical characteristics of the vehicle and where the necessary data is made available, with the use of electronic interface	(a) System or any component missing		Х	
in the vehicle and is used to propel the vehicle, either by combustion in		(b) System or components damaged		Х	
an internal combustion engine or by conversion in a fuel cell with an		(c) Software version or -integrity incorrect		Х	
additional electric engine.		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	

· · · · · · · · · · · · · · · · · · ·				1	
		(h) Other failure Not affecting the safe operation	x		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.31 Start-up aid Description: aiding start-up, for	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
example by raising the lift axle or by momentarily applying brake	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		х	
pressure or by automatic release of the parking brake.	use of electronic interface	(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	x		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	x		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.32 Trailer stabilization Description: through selective	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
braking of the trailer by the service brakes, the complete vehicle train is stabilised.	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
	use of electronic interface	(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	

				1	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.33 Endurance brake Description: an additional braking system that can maintain braking	activated and not activated, if possible) complemented, where made possible by the technical characteristics of the vehicle and where the necessary data is made available, with the use of electronic	(a) System or any component missing (for example Insecure connectors or mountings)		Х	
over a period of time without a significant reduction in		(b) System or components damaged		Х	
performance, for example in accordance with UNECE-R 13 and		(c) Software version or -integrity incorrect		Х	
Regulation (EU) 2019/2144.		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	

		(j) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.34 Differential lock deactivation Description: when this system is	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
activated, the differential locks are unlocked depending on parameters	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
(for example wheel slip, steering angle, speed).	use of electronic interface	(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	x		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		Steering affected			
					Х
		(h) Other failure Not affecting the safe operation	x		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			х
10.35 Electronically controlled leading and trailing axle	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
Description: the steered axles are	characteristics of the vehicle and where the	(b) System or components damaged		Х	

			1		· · · · · · · · · · · · · · · · · · ·
additional axles with electronically controlled steering. The steering	use of electronic interface	(c) Software version or -integrity incorrect		Х	
force is generated by a hydraulic pump or by the lateral force on the wheels.		(d) Wiring damaged		Х	
wheels.		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	x		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			х
		(g) System or components not operating, or implausible operation		Х	
		Steering affected			
					х
		(h) Other failure Not affecting the safe operation	x		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.36 Electronic steering damper Description: Steering damping is	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
controlled electronically.	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
	use of electronic interface	(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	

			r		
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		Steering affected			
					Х
		(h) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.37 Bus stop brake Description: the system ensures the	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
application of brake pressure when stationary, independent of the brake	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
pedal activation. Buses can only start moving when the doors are		(c) Software version or -integrity incorrect		Х	
closed.		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			х
		(g) System or components not operating, or implausible operation		Х	

		(h) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.38 Kneeling Description: the system allows a	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
road vehicle to be lowered to make it easier for passengers to board and	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		х	
disembark.	use of electronic interface	(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.39 Steering brake Description: during cornering, dosed	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
braking is applied to one or more wheels.	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
	use of electronic interface	(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	

		(e) Warning device shows system malfunction.		X	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	X		
		Affecting safe operation of the vehicle		х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		Steering affected			
		Steering affected			х
		(h) Other failure Not affecting the safe operation	X		
		Affecting safe operation of the vehicle		х	
		Danger to health of persons on board or of other road users			Х
10.40 Tyre pressure control Description: according to the	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		х	
requirement of the driver, the system regulates the tyre pressure.	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
	use of electronic interface	(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	

		(h) Other failure Not affecting the safe operation	x		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.41 Sliding joint stabilisation Description: The articulated joint is	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
stabilised by damping, depending on vehicle speed, cylinder pressure of	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		х	
the articulated dampers, steering and articulation-angle.	use of electronic interface	(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	X		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		х	
		(h) Other failure Not affecting the safe operation	x		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.42 Four-wheel parking brake Description: the system applies the	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
maximum brake pressure in the wheel cylinders at all four wheels.	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
	use of electronic interface	(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	

					1
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	x		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.43 Front-wheel locking device Description: front wheel suspension,	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
which permits lateral inclination of the motorcycle, can be locked and	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
unlocked by an electric actuator. Above a certain speed, it is	use of electronic interface	(c) Software version or -integrity incorrect		Х	
automatically unlocked.		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	x		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	

		(h) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.44 Adaptive headlights Description: the illumination of the	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
surrounding road area and/or the direct illumination of road users in	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
the danger area in front of the vehicle is optimised by dynamic	use of electronic interface	(c) Software version or -integrity incorrect		Х	
adaption of the light beams.		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	x		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	x		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.45 Electrically actuated parking brake	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
Description: the parking brake function is triggered or transmitted	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
electronically or electromechanically.	use of electronic interface	(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	

			1		
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	x		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	x		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.46 Lane change assistance Description: at a lane change, the	made possible by the technical	(a) System or any component missing		Х	
system warns the driver about vehicles in the next lane and steers		(b) System or components damaged		Х	
the vehicle back.	use of electronic interface	(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	X		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	

		(h) Other failure Not affecting the safe operation	x		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.47 Lane keeping assistance Description: the system warns the	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
driver when the vehicle is unintentionally leaving its lane and	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
steers the vehicle back, e.g. in accordance with Regulation (EU)	use of electronic interface	(c) Software version or -integrity incorrect		Х	
2019/2144 and Commission Implementing Regulation (EU) 2021/646*.		(d) Wiring damaged		Х	
2021/040*.		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	x		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	x		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.48 Automatic eCall Description: the system is triggered	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
automatically by in-vehicle sensors or manually, it transmits a minimum	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
set of data (EN 15722) via mobile communication network and	use of electronic interface	(c) Software version or -integrity incorrect		Х	
establishes an audio connection based on the (emergency) number		(d) Wiring damaged		Х	

between the vehicle passengers and	The verification of the minimum set of data	() We arise device (CollAMI) down and some of the strength		x	
the public safety answering point, in accordance with Regulation (EU)	(FID	(e) Warning device (eCall MIL) shows system malfunction.		А	
2015/758 of the European Parliament and of the Council**, and Commission Delegated	<ul> <li>the mandatory fields are filled with plausible information;</li> <li>the deviation between in-vehicle</li> </ul>	(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	х		
Regulation (EU) 2017/79***.	system (IVS) location and true location is less than 150 meters.	Affecting safe operation of the vehicle		Х	
	The calculation can be done according to point 2.5 of Annex I	Danger to health of persons on board			Х
	of Commission Delegated Regulation (EU) 2017/79; - the deviation between the MSD timestamp and the timestamp of the reading is less than 60s.	<ul> <li>(g) System or components not operating, or implausible operation:</li> <li>- audio components (for example failing echo-test);</li> <li>- minimum set of data incorrect</li> </ul>		Х	
		(h) Other failure (for example mobile network communication device, electronic control unit, or GPS signal failure) Not affecting the safe operation	Х	V	
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board			Х
10.49 Active roll stabilisation Description: via appropriate	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
actuators the system produces a roll movement which counters the	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
vehicle's body roll movement depending on the current driving	use of electronic interface	(c) Software version or -integrity incorrect		Х	
situation.		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	

		(h) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.50 Camera monitor Description: the system which	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
generates at least a part of the indirect field of vision by a camera	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
monitor combination (for example in accordance with UNECE-R 46).	use of electronic interface	(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.51 Acoustic vehicle alerting Description: at low speed, the	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
system generates an external, specific sound in order to warn, for	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
example pedestrians.	use of electronic interface	(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	

			1		
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operative, or not respecting type-approved noise levels		Х	
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.52 Basic exterior lights Description: the system switches	made possible by the technical	(a) System or any component missing		х	
on/switches off the basic lighting devices (for example indicators).		(b) System or components damaged		Х	
	use of electronic interface	(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	

		(h) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.53 Automated lane keeping system (ALKS)	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
Description: a system which is activated by the driver, and which	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
keeps the vehicle within its lane by controlling the lateral and	use of electronic interface	(c) Software version or -integrity incorrect		Х	
longitudinal movements of the vehicle for extended periods without the need		(d) Wiring damaged		Х	
for further driver input (for example in accordance with UNECE-R 157).		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	x		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	x		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.54 Turning assistant Description: a system to inform the	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
driver of a possible collision with a traffic participant (for example	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
bicycle) near side (for example in accordance with UNECE-R 151).	use of electronic interface	(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	

				r	<b>.</b>
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.55 Tachograph Description: a system to record the driving time, breaks, rest periods as well as periods of other work	made possible by the technical characteristics of the vehicle and where the necessary data is made available, with the use of electronic interface	(a) System or any component missing (for example seals, plaques), or not fitted in accordance with the requirements (for example plaque out of date).		Х	
undertaken by a driver, for example, in accordance with Regulation (EU)		(b) System or components damaged (for example illegible plaque)		Х	
No 165/2014 of the European Parliament and of the Council****.		(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	
		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation (for example tampered or manipulated, or size of tyres not compatible with calibration parameters, or incorrect set speed, if checked).		Х	

					1
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.56 Intelligent speed assistance Description: system to aid the driver	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
in maintaining the appropriate speed for the road environment by	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
providing dedicated and appropriate feedback, for example in accordance	use of electronic interface	(c) Software version or -integrity incorrect		Х	
with Regulation (EU) 2019/2144 and Commission Delegated		(d) Wiring damaged		Х	
Regulation (EU) 2021/1958*****.		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(g) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.57 Reversing detection Description: system to make the	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
driver aware of people and objects at the rear of the vehicle with the	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
primary aim of avoiding collisions when reversing, for example in	use of electronic interface	(c) Software version or -integrity incorrect		Х	
		(d) Wiring damaged		Х	

accordance with Regulation (EU) 2019/2144 and UNECE-R 158.		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	x		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.58 Driver drowsiness and attention warning	1 1 /	(a) System or any component missing		Х	
Description: system that assesses the driver's alertness through vehicle	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
systems analysis and warns the driver if needed, for example in	use of electronic interface	(c) Software version or -integrity incorrect		Х	
accordance with Regulation (EU) 2019/2144 and Commission Delegated Regulation (EU)		(d) Wiring damaged		Х	
Delegated Regulation (EU) 2021/1341*****		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	

			1	1	
		(h) Other failure Not affecting the safe operation	x		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.59 Advanced driver distraction warning	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
Description: system that helps the driver to continue to pay attention to	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
the traffic situation and that warns the driver when he or she is	use of electronic interface	(c) Software version or -integrity incorrect		Х	
distracted, for example in accordance with Regulation (EU) 2019/2144 and Commission		(d) Wiring damaged		Х	
Delegated Regulation (EU) 2023/2590******		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	x		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation		Х	
		(h) Other failure Not affecting the safe operation	x		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
10.60 Event data recorder Description: system with the only	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
purpose of recording and storing critical crash-related parameters and	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
information shortly before, during and immediately after a collision, for	use of electronic interface	(c) Software version or -integrity incorrect		Х	
example in accordance with Regulation (EU) 2019/2144,		(d) Wiring damaged		Х	

Commission Delegated Regulation					1
(EU) 2022/545*******, and		(e) Warning device shows system malfunction.		Х	
UNECE-R 160.		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	х		
		(g) System or components not operating, or implausible operation (for example data not accessible)		Х	
		(h) Other failure Not affecting the safe operation	X		
10.61 Automated driving system Description: systems that are	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
capable of performing the entire dynamic driving task of the fully	characteristics of the vehicle and where the necessary data is made available, with the	(b) System or components damaged		Х	
automated vehicle on a sustained basis, for example in accordance	use of electronic interface	(c) Software version or -integrity incorrect		Х	
with Regulation (EU) 2019/2144 and Commission Implementing		(d) Wiring damaged		Х	
Regulation (EU) 2022/1426*******.		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation (for example HMI)		Х	
		(h) Other failure Not affecting the safe operation	х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			х
10.62 Driver availability monitoring systems (automated driving)	Visual inspection complemented, where made possible by the technical	(a) System or any component missing		Х	
Description: System that assesses	characteristics of the vehicle and where the	(b) System or components damaged		Х	

whether the driver is capable of taking over the driving function of a	necessary data is made available, with the use of electronic interface	(c) Software version or -integrity incorrect		Х	
self-driving vehicle, if necessary, in certain situations, for example in accordance with Regulation (EU)		(d) Wiring damaged		Х	
2019/2144 and UNECE-R 157.		(e) Warning device shows system malfunction.		Х	
		(f) System indicates failure via the electronic vehicle interface Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х
		(g) System or components not operating, or implausible operation (for example HMI)		Х	
		(h) Other failure Not affecting the safe operation	Х		
		Affecting safe operation of the vehicle		Х	
		Danger to health of persons on board or of other road users			Х

<sup>\*</sup> Commission Implementing Regulation (EU) 2021/646 of 19 April 2021 laying down rules for the application of Regulation (EU) 2019/2144 of the European Parliament and of the Council as regards uniform procedures and technical specifications for the type-approval of motor vehicles with regard to their emergency lane-keeping systems (ELKS) (OJ L 133, 20.4.2021, p. 31, ELI: http://data.europa.eu/eli/reg\_impl/2021/646/oj).

<sup>\*\*</sup> Regulation (EU) 2015/758 of the European Parliament and of the Council of 29 April 2015 concerning type-approval requirements for the deployment of the eCall in-vehicle system based on the 112 service and amending Directive 2007/46/EC (OJ L 123, 19.5.2015, p. 77, ELI: <u>http://data.europa.eu/eli/reg/2015/758/oj).</u>

<sup>\*\*\*</sup> Commission Delegated Regulation (EU) 2017/79 of 12 September 2016 establishing detailed technical requirements and test procedures for the EC type-approval of motor vehicles with respect to their 112-based eCall in-vehicles systems, of 112-based eCall in-vehicle separate technical units and components and supplementing and amending Regulation (EU) 2015/758 of the European Parliament and of the Council with regard to the exemptions and applicable standards (OJ L 12, 17.1.2017, p. 44, ELI: <u>http://data.europa.eu/eli/reg\_del/2017/79/oj)</u>.

\*\*\*\* Regulation (EU) No 165/2014 of the European Parliament and of the Council of 4 February 2014 on tachographs in road transport, repealing Council Regulation (EEC) No 3821/85 on recording equipment in road transport and amending Regulation (EC) No 561/2006 of the European Parliament and of the Council on the harmonisation of certain social legislation relating to road transport (OJ L 60, 28.2.2014, p. 1, ELI: <u>http://data.europa.eu/eli/reg/2014/165/oj</u>).

\*\*\*\*\* Commission Delegated Regulation (EU) 2021/1958 of 23 June 2021 supplementing Regulation (EU) 2019/2144 of the European Parliament and of the Council by laying down detailed rules concerning the specific test procedures and technical requirements for the type-approval of motor vehicles with regard to their intelligent speed assistance systems and for the type-approval of those systems as separate technical units and amending Annex II to that Regulation (OJ L 409, 17.11.2021, p. 1, ELI: <u>http://data.europa.eu/eli/reg\_del/2021/1958/oj</u>).

\*\*\*\*\* Commission Delegated Regulation (EU) 2021/1341 of 23 April 2021 supplementing Regulation (EU) 2019/2144 of the European Parliament and of the Council by laying down detailed rules concerning the specific test procedures and technical requirements for the type-approval of motor vehicles with regard to their driver drowsiness and attention warning systems and amending Annex II to that Regulation (OJ L 292, 16.8.2021, p. 4, ELI: <u>http://data.europa.eu/eli/reg\_del/2021/1341/oj</u>).

\*\*\*\*\*\* Commission Delegated Regulation (EU) 2023/2590 of 13 July 2023 supplementing Regulation (EU) 2019/2144 of the European Parliament and of the Council by laying down detailed rules concerning the specific test procedures and technical requirements for the type-approval of certain motor vehicles with regard to their advanced driver distraction warning systems and amending that Regulation (OJ L, 2023/2590, 22.11.2023, ELI: <u>http://data.europa.eu/eli/reg\_del/2023/2590/oj</u>).

\*\*\*\*\*\*\* Commission Delegated Regulation (EU) 2022/545 of 26 January 2022 supplementing Regulation (EU) 2019/2144 of the European Parliament and of the Council by laying down detailed rules concerning the specific test procedures and technical requirements for the type-approval of motor vehicles with regard to their event data recorder and for the type-approval of those systems as separate technical units and amending Annex II to that Regulation (OJ L 107, 6.4.2022, p. 18, ELI: <u>http://data.europa.eu/eli/reg\_del/2022/545/oj).</u>

\*\*\*\*\*\*\*\* Commission Implementing Regulation (EU) 2022/1426 of 5 August 2022 laying down rules for the application of Regulation (EU) 2019/2144 of the European Parliament and of the Council as regards uniform procedures and technical specifications for the type-approval of the automated driving system (ADS) of fully automated vehicles (OJ L 221, 26.8.2022, p. 1, ELI: <u>http://data.europa.eu/eli/reg\_impl/2022/1426/oj).</u>

(2) Annex III is amended as follows:

The first sentence in Chapter II, Section 3, is replaced by the following:

'Table 1 sets out rules that shall be applied during a cargo securing inspection to determine whether the condition of the transport is acceptable.';

- (3) Annex IV is amended as follows:
- (a) on the front side of the form, point 6 is replaced by the following:
  - '6. Category of vehicle<sup>(a)</sup>

(a)	$N_1$ (up to 3,5 t)	
(b)	$N_2$ (3,5 to 12 t)	
(c)	$N_3$ (more than 12 t)	
(d)	O <sub>3</sub> (3,5 to 10 t)	
(e)	O <sub>4</sub> (more than 10 t)	
(f)	$M_2$ (more than 9 seats <sup>(b)</sup> , up to 5 t)	
(g)	M <sub>3</sub> (more than 9 seats <sup>(b)</sup> , more than 5 t)	
(h)	T1b	
(i)	T2b	
(j)	ТЗЬ	
(k)	T4.1b	
(1)	T4.2b	
(m)	T4.3b	
(n)	Other vehicle category:	
	(please specify).';	
point	t 10 is amended as follows:	
(i) poi	nt (10) is replaced by the following:	

(b)

- '(10) Electronic safety systems<sup>(f)</sup>';
- (ii) the following point (11) is added:
- (11) Cargo securing<sup>(f)</sup>;
- (c) the reverse side of the form is amended as follows:

(i) the following item 4.14 is inserted:

- '4.14 High-voltage systems
- 4.14.1 Electrical safety
- 4.14.2 Traction battery cover
- 4.14.3 Traction battery
- 4.14.4 High-voltage electrical wiring
- 4.14.5 High-voltage electrical and electronical equipment
- 4.14.6 Insulation resistance
- 4.14.7 Anti-starting system';
- (ii) items 8.2.1 to 8.2.2.2 are replaced by the following:
  - '8.2.1 Exhaust emissions control equipment
  - 8.2.2 Exhaust emission measurement positive ignition engines
  - 8.2.2.1 Particle number measurement
  - 8.2.2.2 Gaseous emissions
  - 8.2.2.3 NO<sub>X</sub> measurement
  - 8.2.3 Exhaust emission measurement compression ignition engines
  - 8.2.3.1 Particle number measurement
  - 8.2.3.2 Opacity

8.2.3.3 NO<sub>X</sub> measurement';

(iii) the following item 10 is added:

'10. Electronic safety systems in accordance with Annex II to Directive 2014/47/EU'.

# (4) Annex V is replaced by the following:

# 'ANNEX V

# STANDARD FORM FOR REPORTING TO THE COMMISSION

The standard form shall be drawn up in a computer-processable format and transmitted by electronic means using standard office software. Each Member State shall produce both the following tables:

- (a) one summary table per year;
- (b) for each country of registration of vehicles checked in a more detailed inspection, a separate table containing information on checked and detected deficiencies for each vehicle category.

## Summary table

#### of all (initial and more detailed) inspections

Reporting Member State:

Reporting period

year [X]

Vehicle Category:	N	[1	Ν	J <sub>2</sub>	Ν	I <sub>3</sub>	Ν	12	Ν	13	C	<b>D</b> <sub>3</sub>	C	<b>D</b> <sub>4</sub>	T1b, T2 T4.1b, T4 T4	4.2b, and	Other ca (optio		То	otal
Country of registration	Number of vehicles checked ( <sup>1</sup> )	Number of vehicles failed ( <sup>2</sup> )	Number of vehicles checked	Number of vehicles failed																
Belgium																				
Bulgaria																				
Czech Republic																				
Denmark																				
Germany																				
Estonia																				
Ireland																				
Greece																				
Spain																				
France																				
Croatia																				
Italy																				
Cyprus																				
Latvia																				
Lithuania																				

Vehicle Category:	Number Number		N <sub>2</sub>		N <sub>3</sub>		M2		Ν	⁄I <sub>3</sub>	C	<b>D</b> <sub>3</sub>	O <sub>4</sub>		T1b, T2 T4.1b, T T4	4.2b, and	Other ca (opti	ntegories onal)	To	otal
Country of registration	Number of vehicles checked	Number of vehicles failed																		
Luxembourg																				
Hungary																				
Malta																				
Netherlands																				
Austria																				
Poland																				
Portugal																				
Romania																				
Slovenia																				
Slovakia																				
Finland																				
Sweden																				
Albania																				
Andorra																				
Armenia																				
Azerbaijan																				

Vehicle Category:	N <sub>1</sub> N <sub>2</sub>		J <sub>2</sub>	N <sub>3</sub>		M <sub>2</sub>		Ν	13	0	<b>D</b> <sub>3</sub>	C	<b>D</b> <sub>4</sub>	T1b, T2 T4.1b, T4 T4	4.2b, and	Other ca (opti		Tc	otal	
Country of registration	Number of vehicles checked	Number of vehicles failed																		
Belarus																				
Bosnia and Herze- govina																				
Georgia																				
Kazakhstan																				
Liechtenstein																				
Monaco																				
Montenegro																				
North Macedonia																				
Norway																				
Republic of Moldova																				
Russian Federation																				
San Marino																				
Serbia																				
Switzerland																				
Tajikistan																				
Türkiye																				
Turkmenistan																				

Vehicle Category:	N	N <sub>1</sub>		N <sub>2</sub>		N <sub>3</sub>		M <sub>2</sub>		M <sub>3</sub>		O <sub>3</sub>		O <sub>4</sub>		2b, T3b, 4.2b, and .3b	Other ca (opti	ntegories onal)	Тс	otal
Country of registration	Number of vehicles checked	Number of vehicles failed	of	Number of vehicles failed	Number of vehicles checked	Number of vehicles failed	Number of vehicles checked	Number of vehicles failed	Number of vehicles checked	Number of vehicles failed	Number of vehicles checked	Number of vehicles failed	of	Number of vehicles failed	Number of vehicles checked	Number of vehicles failed	Number of vehicles checked	Number of vehicles failed	Number of vehicles checked	Number of vehicles failed
Ukraine																				
United Kingdom																				
Uzbekistan																				
Other third countries (please specify)																				

(1) Total number of vehicles checked (at initial and more detailed inspections), including those without deficiencies, as well as those with minor, major or dangerous deficiencies.

(2) Failed vehicles with major or dangerous deficiencies as per Annex IV.

#### Results of more detailed inspections

## Reporting Member State:

Name of the reporting Member State

Country of Registration:

PERIOD:

year [x]

Name of the country of vehicle registration

	N	J <sub>1</sub>	٢	J <sub>2</sub>	٢	J <sub>3</sub>	N	<b>1</b> 2	Ν	13	0	)3	0	<b>D</b> <sub>4</sub>		2b, T3b, 4.2b, and 3b	Other ca (opti	ategories onal)	То	otal
Vehicle Category:	Number of vehicles checked ( <sup>1</sup> )	Number of vehicles failed ( <sup>2</sup> )	Number of vehicles checked	Number of vehicles failed																
Defect detail																				
	Checked	Failed	Checked	Failed	Checked	Failed	Checked	Failed	Checked	Failed	Checked	Failed	Checked	Failed	Checked	Failed	Checked	Failed	Checked	Failed
(0) Identification																				
(1) Braking equipment																				
(2) Steering																				
(3) Visibility																				
<ul><li>(4) Lighting equipment and electrical system</li></ul>																				
(5) Axles, wheels, tyres, suspension																				

(6) Chassis and chassis attachments

	Ν	Į,	٢	<b>J</b> 2	Ν	J <sub>3</sub>	Ν	12	Ν	13	0	<b>D</b> <sub>3</sub>	C	<b>D</b> <sub>4</sub>	T1b, T2 T4.1b, T T4		Other ca (opti		То	otal
Vehicle Category:	Number of vehicles checked	Number of vehicles failed																		
	Checked	Failed																		
<ul><li>(7) Other equipment including tachograph and speed limitation devices</li></ul>																				
(8) Nuisance including emissions and spillage of fuel and/or oil																				
(9) Supplementary tests for M <sub>2</sub> /M <sub>3</sub>																				
(10) Electronic safety systems																				
(11) Cargo securing																				
Total number of failures																				

(1) Total number of vehicles checked (at initial and more detailed inspections), including those without deficiencies, as well as those with minor, major or dangerous deficiencies.

 $(^2)$  Failed vehicles with major or dangerous deficiencies as per Annex IV.

EN